


# **SKYDECK**Panel Slab Formwork

Instructions for Assembly and Use – Standard Configuration



Edition 09 | 2016

### **Content**




_					
Over			A9	SKYDECK platforms	46
	Main components	1		Corner table (Area I)	47
	Key	2		Cantilevers (Area II)	51
	Presentational reference	2		Open edge areas (Area III)	52
Intro	duction			Slab areas (Area IV)	52
	Target groups	3		Infill areas	52
	Additional technical documentation	3		Platform installation	53
	Intended use	4		Striking	54
	Care and maintenance instructions	5		Working and safety scaffold	55
	Instructions for Use	5	A10	Changing direction	56
Safet	ty instructions			- System with Prophead SSK	56
	Cross-system	6		- System with Drophead SFK	58
	System-specific	7	A11	Inclined slabs	60
	Storage and transportation	7		Bracing with Tension Sleeve SAO and	
				Chain 3.0 kN	60
Stan	dard configuration			Bracing with Tension Unit SD	61
A1	Storage and transportation	8	A12	Striking	62
A2	System components	11	A13	Site record	64
A3	System dimensions	14	, (10	310 100010	0 1
710	Notes regarding static calculations	14	Desi	gn tables	
	Internal forces and rigidity	15	A14	Horizontal loads with Slab Props PEP	65
	Load combinations	15	A15	Inclined slabs	66
A4	Shuttering	17	713	Maximum permissible slab inclination with	00
A4		17		Tension Sleeve SAO and Chain 3.0 kN	66
	Starting bay				66
	Transverse bay	19 20		Tension Unit SD – bracing angle	00
	Longitudinal bay	20		Tensile force of Tension Unit SD and	
۸.	Standard bay			prop loads	07
A5	Compensations	24		- System with Drophead SFK	67
	System components	24	110	- System with Prophead SSK	70
	Edge Beam SRT 150, SRT 75	24	A16	SKYDECK standard configuration	73
	Filler Timber SPH	24		Prop loads	
	End Support SSL	24		- System with Drophead SFK	73
	Combinead SCK	25		<ul> <li>System with Prophead SSK</li> </ul>	74
	Triangular Frame SDR 150/75, 75/75	28		– Panel system	75
	Longitudinal compensations	28		Striking guide values	75
	Transverse compensations	31	A17	Filler plates, forming around columns	76
A6	Shuttering around columns	34	A18	Slab props	77
	1 recessed panel	34		– PEP 20	77
	2 recessed panels	35		– PEP 20 with Base MP 50	78
	3 recessed panels	36		– PEP 30	79
	Recessed main beams	37		– PEP 30 with Base MP 50	80
	Shifting the main beam axis	37		– PEP Ergo B	81
A7	Horizontal bracing	38		– PEP Ergo D	82
	Transfer of horizontal loads into the			– PEP Ergo E	83
	columns of the building	38		– MULTIPROP 250, 350, 480, 625	84
	General	39			
	Bracing of the inner bay	39	Com	ponents	
	Transfer of horizontal loads from a			Components	86
	casting segment	40			
A8	Cantilevers, Guardrails	42			
	Bracing on leading edges to prevent				
	tipping	42			
	Guardrails with Handrail Unit SD	43			
	SKYDECK Guardrail Holder SGH and				
	Guardrail Post SGP	44			

### **Overview**



### Main components



### **Overview**



#### Key

#### Pictogram | Definition



Safety instructions



Note



Load-bearing point



Visual check



Tin



Personal protective equipment to prevent falling from a height (PPE)



Misapplication



Correct application

#### **Dimension specifications**

Dimensions are usually given in cm. Other units of measure, e.g. m, are shown in the illustrations. Load details are usually given in kg. Other measurement units, e.g. t, are specified in the illustrations.

#### **Conventions**

- Instructions are numbered with:1. ....., 2. ......, 3. .....
- The result of an instruction is shown by: →
- Position numbers are clearly provided for the individual components and are given in the drawing, e.g. 1, in the text in brackets, for example (1).
- Multiple position numbers, i.e. alternative components, are represented with a slash, e.g. 1 / 2.

#### Arrows

- → Arrow representing an action
- Arrow representing a reaction of an action\*
- → Forces
- \* If not identical to the action arrow

#### **Presentational reference**

The illustration on the front cover of these instructions is understood to be a system representation only. The assembly steps presented in these Instructions for Assembly and Use are shown in the form of examples with only one component size. They are valid accordingly for all component sizes contained in the standard configuration.

For a better understanding, detailed illustrations are partly incomplete. The safety installations which have possibly not been featured in these detailed drawings must nevertheless still be available.

### Introduction



#### **Target groups**

#### Contractors

These Instructions for Assembly and Use are designed for contractors who use the formwork systems for

- assembling, modifying and dismantling, or
- use them, e.g. for concreting, or
- for other operations, e.g. carpentry or electrical work.

#### **Construction site coordinator**

The Safety and Health Protection Coordinator\*

- is appointed by the client,
- must identify potential hazards during the planning phase,
- determines measures that provide protection against risks,
- creates a safety and health plan,
- coordinates the protective measures for the contractor and site personnel so that they do not endanger each other,
- monitors compliance with the protective measures.

#### **Competent persons**

Due to the specialist knowledge gained from professional training, work experience and recent professional activity, the competent person has a reliable understanding of safety-related issues and can correctly carry out inspections. Depending on the complexity of the test to be undertaken, e.g. scope of testing, type of testing or the use of a certain measuring device, a range of specialist knowledge is necessary.

#### **Qualified persons**

Formwork systems may only be assembled, modified or dismantled by personnel who are suitably qualified to do so. For the work to be carried out, the qualified persons must have received instructions\*\* which contain at least the following points:

- Explanation of the plan for the assembly, modification or dismantling of the formwork in an understandable form and language.
- Description of the measures for assembling, modifying or dismantling the formwork.
- Designation of the preventive measures to avoid the risk of persons and objects falling.

- Designation of the safety precautions in the event of changing weather conditions which could adversely affect the safety of the formwork system as well as the personnel concerned.
- Details regarding the permissible loads.
- Description of any other risks that are associated with the assembly, modification or dismantling procedures.



In other countries, ensure that the relevant national guidelines and regulations in the respective current version are complied with!

#### Additional technical documentation

- Poster: SKYDECK
- MULTIPROP Slab Props: Instructions for Assembly and Use
- PEP Ergo Slab Props: Instructions for Assmbly and Use
- Instructions for Use:
  - Pallet Lifting Truck
  - Pallets and Stacking Devices
  - Stripping Cart ASW 465
  - Stripping Cart Alu
  - Transportation Fork SKYDECK SUG
- Technical Data Sheet for Anchor Bolt PERI 14/20 x 130
- PERI Design Tables Formwork and Shoring
- Brochures:
  - SKYDECK
  - SKYDECK Beam Waler SD

Valid in Germany: Regulations for Occupational Health and Safety on Construction Sites 30 (RAB 30)-

<sup>\*\*</sup> Instructions are given by the contractor himself or a competent person selected by him.

### Introduction



#### Intended use

#### **Product description**

PERI products have been designed for exclusive use in the industrial and commercial sectors by qualified users only.

PERI SKYDECK is a panel slab formwork system used for constructing slab thicknesses up to 109 cm. Depending on the slab thickness and concrete strength, the SKYDECK Drophead allows striking to take place after only 1 day: see table containing minimum concrete strength and striking guide values.

The SKYDECK Platform is a prefabricated, folding scaffold platform for use as working and safety scaffold according to DIN 4420 Part 1. Immediately after concreting, it is available as safety scaffold to provide safe and secure working conditions on rising structures.

Classification is effected in Scaffold Group 2 (useful load per surface 150 kg/m²) . It is required for concreting floor slabs in skeleton construction (high-rise buildings) and for securing the open edges of the SKYDECK Slab Formwork System. A 1.30 m wide platform with guardrails provides safe working conditions on the slab edges.

#### **Features**

The panels and main beams are made of aluminium which means they are very light.

Accessories for infill areas, shuttering around columns and the slab edges are also available.

Due to early striking, the panels and main beams can be used for the next concreting cycle.

Only the props with dropheads and the cover strips remain in position until the full concrete strength has been reached. On-site material requirements are therefore clearly reduced.

For supporting the SKYDECK panels, PERI MULTIPROPs or PEP Slab Props can be used.

The SKYDECK Platform consists of:

- 39 mm thick plywood decking fixed to a supporting frame,
- a folding handrail unit that is screwed to the supporting frame as a framed construction, and held by a securing lever when opened up.

The platform can be used on the edge of the floor slab as well as in the corner table area. For the various applications, three lengths are available.

SDB 150 L = 1.50 m SDB 225 L = 2.25 m SDB 300 L = 3.00 m

The SDB 225 Platform can also be used for side cantilevers of 75 cm to the right or left of the main beam.

Assembly of the platform takes place with the crane from the outside of the building. It is set down on the cantilevered main beams and automatically locks in position.

All steel parts are galvanized while all safety components are red powder-coated.

#### Technical data System dimensions With Drophead SFK, Main Beam SLT 225

- 230 x 150 cm, slab thickness max.
   43 cm, as standard case presented in the Instructions for Assembly and
- 230 x 75 cm, slab thickness max.90 cm
- 115 x 75 cm, slab thickness max.
   109 cm with centre support

#### With Drophead SFK, Main Beam SLT 150

- 155 x 150 cm, slab thickness max.52 cm
- 155 x 75 cm, slab thickness max.109 cm

#### With Prophead SSK, Main Beam SLT 225

- 225 x 150 cm, slab thickness max.43 cm
- 225 x 75 cm, slab thickness max.90 cm
- 112.5 x 75 cm, slab thickness max.
   109 cm with centre support

#### With Prophead SSK, Main Beam SLT 150

 $150 \times 150 \text{ cm}$ , slab thickness max. 55 cm

 $150 \times 75$  cm, slab thickness max. 109 cm

For permissible slab thicknesses and available prop loads: see PERI Design Tables.

### Introduction



#### Care and maintenance instructions

In order to maintain the value and operational readiness of the formwork materials over the long term, clean the elements after each use.

Some repair work may also be inevitable due to the tough working conditions. The following points should help to keep care and maintenance costs as low as possible.

Spray the formwork on both sides with concrete release agent before each use; this allows easier and faster cleaning of the formwork. Spray the concrete release agent very thinly and evenly!

Spray the rear side of the formwork with water immediately after concreting; this avoids any time-consuming and costly cleaning operations.

When used continuously, spray the panel formlining with the concrete release agent immediately after striking; then clean by means of a scraper, brush or rubber lip scraper.

Important: do not clean formlining made of plywood with high-pressure equipment; this could result in the formlining being damaged.

Fix box-outs recesses and mounting parts with double-headed nails; as a result, the nails can be easily removed later, and damage to the formlining is largely avoided.

Close all unused anchor holes with plugs; this eliminates any subsequent cleaning or repair work.

Anchor holes accidentally blocked with concrete are freed by means of a steel pin from the formlining side.

When placing bundles of reinforcement bars or other heavy objects on horizontally-stored formwork elements, suitable support, e.g. square timbers, is to be used; as a result, impressions and damage to the formlining are largely avoided.

Internal concrete vibrators should be fitted with rubber caps if possible; as a result, any damage to the formlining is reduced if the vibrator is accidently "inserted" between the reinforcement and formlining. Never clean powder-coated components, e.g. elements and accessories, with a steel brush or hard metal scraper; this ensures that the powder-coating remains intact.

Use spacers for reinforcement with large-sized supports or extensive areas of support; this largely avoids impressions being formed in the formlining when under load.

Mechanical components, e.g. spindles or gear mechanisms, must be cleaned of dirt or concrete residue before and after use, and then greased with a suitable lubricant.

Provide suitable support for the components during cleaning so that no unintentional change in their position is possible.

Do not clean components when suspended on a crane.

#### Instructions for Use

The use in a way not intended according to the Instructions for Assembly and Use, or any use deviating from the standard configuration or the intended use represents a misapplication with a potential safety risk, e.g. risk of falling.

Only PERI original components may be used. The use of other products and spare parts is not allowed.

Changes to PERI components are not permitted.

### **Safety instructions**



#### **Cross-system**

#### General

The contractor must ensure that the Instructions for Assembly and Use supplied by PERI are available at all times and are understood by the site personnel

These Instructions for Assembly and Use can be used as the basis for creating a risk assessment. The risk assessment is compiled by the contractor. The Instructions for Assembly and Use do not replace the risk assessment!

Always take into consideration and comply with the safety instructions and permissible loads.

For the application and inspection of PERI products, the current safety regulations and guidelines must be observed in the respective countries where they are being used.

Materials and working areas are to be inspected on a regular basis especially before each use and assembly for:

- signs of damage,
- stability and
- function.

Damaged components must be exchanged immediately on site and may no longer be used.

Safety components are to be removed only when they are no longer required.

Components provided by the contractor must conform with the characteristics required in these Instructions for Assembly and Use as well as with all valid construction guidelines and standards. In particular, the following applies if nothing else is specified:

- Timber components: Strength Class C24 for Solid Wood according to EN 338.
- Scaffold tubes: galvanised steel tubes with minimum dimensions of Ø 48.3 x 3.2 mm according to EN 12811-1:2003 4.2.1.2.
- Scaffold tube couplings according to EN 74.

Deviations from the standard configuration are only permitted after a further risk assessment has been carried out by the contractor. On the basis of this risk assessment, appropriate measures for working and operational safety as well as stability are to be determined. Corresponding proof of stability can be provided by PERI on request if the risk assessment and resulting measures to be implemented are made available.

Before and after exceptional occurrences that may have an adverse effect regarding the safety of the formwork system, the contractor must immediately

- create another risk assessment, with appropriate measures for ensuring the stability of the formwork system being carried out based on the results.
- and arrange for an extraordinary inspection by a competent person. The aim of this inspection is to identify and rectify any damage in good time in order to guarantee the safe use of the formwork system.

Exceptional occurrences can include:

- accidents,
- Ionger periods of non-use,
- natural events, e.g. heavy rainfall, icing, heavy snowfall, storms or earthquakes.

### Assembly, modification and dismantling work

Assembly, modification or dismantling of formwork systems may only be carried out by qualified persons under the supervision of a competent person. The qualified persons must have received appropriate training for the work to be carried out with regard to specific risks and dangers.

On the basis of the risk assessment and Instructions for Assembly and Use, the contractor must create installation instructions in order to ensure safe assembly, modification and dismantling of the formwork system.

The contractor must ensure that the personal protective equipment required for the assembly, modification or dismantling of the system, e.g.

- safety helmet,
- safety shoes,
- safety gloves,
- safety glasses,

is available and used as intended.

If personal protective equipment against falling (PPE) is required or specified in local regulations, the contractor must determine appropriate attachment points on the basis of the risk assessment.

The personal protective equipment against falling to be used is determined by the contractor.

The contractor must

- provide safe working areas for site personnel which are to be reached through the provision of safe access ways. Areas of risk must be cordoned off and clearly marked.
- ensure the stability during all stages of construction, in particular during assembly, modification and dismantling of the formwork.
- ensure and prove that all loads can be safely transferred.

#### Utilisation

Every contractor who uses or allows formwork systems or sections of the formwork to be used, has the responsibility for ensuring that the equipment is in good condition.

If the formwork system is used successively or at the same time by several contractors, the health and safety coordinator must point out any possible mutual hazards and all work must be then coordinated.

### Safety instructions



#### System-specific

Retract components only when the concrete has sufficiently hardened and the person in charge has given the goahead for striking to take place.

Anchoring is to take place only if the anchorage has sufficient concrete strength.

In order to avoid an overloading of the integrated temporary props, the load-bearing capacity of the slabs, plates and beams which have already been completed must be activated. For this, a free deflection possibility of these components is required. This takes place by releasing and re-installing all existing temporary props, and is also required for formwork systems where the prop head is an integral part of the slab formwork.

The load-distributing support used, such as planking, must match the respective base. If several layers are required, planks are to be arranged crosswise.

During striking, do not tear off the formwork elements with the crane.

The existing prop loads (see Tables) must be safely transferred by means of sufficiently load-bearing slab props or shoring systems.

SKYDECK Platforms are classified in Load Class 2 (permissible load 1.5 kN/m<sup>2</sup> – 150 kg/m<sup>2</sup>). They are available as working scaffold.

The horizontal fixed position of the slab formwork must be guaranteed. This is given with circumferential walls and pre-concreted beams. Otherwise, the transfer of the horizontal loads has to be guaranteed by means of other measures supplied by the contractor, e.g. bracing. Load assumptions for horizontal loads in accordance with DIN EN 12812.

When storing heavy items on the formwork, the load-bearing capacity must be taken into consideration.

Cantilevers may only be accessed after bracing has been mounted.

With all-round enclosed structure geometries, panels are to be fixed to the main beams by means of two Panel Clips SPK (21) each for wind speeds between 0.033 kN/m² (26 km/h) and dynamic pressure 0.061 kN/m² (36 km/h).

For unfavourable structure geometries or larger wind speeds, additional securing measures are to be implemented,

- e.g.:
- ballast,
- bracing,
- dismantling the formwork etc.

#### Storage and transportation

Store and transport components ensuring that no unintentional change in their position is possible. Detach lifting accessories and slings from the lowered components only if they are in a stable position and no unintentional change is possible.

Do not drop the components.

Use PERI lifting accessories and slings as well as only those load-bearing points provided on the component.

During the moving procedure

- ensure that components are picked up and set down so that unintentional falling over, falling apart, sliding, falling down or rolling is avoided.
- no persons are allowed to remain under the suspended load.

Always guide pre-assembled scaffolding bays, scaffolding units or scaffolding sections with ropes when moving them by crane.

The access areas on the jobsite must be free of obstacles and tripping hazards as well as being slip-resistant.

For transportation, the surface must have sufficient load-bearing capacity.

Use original PERI storage and transport systems, e.g. crate pallets, pallets or stacking devices.

### A1 Storage and transportation





- Instructions for Use for PERI Pallet and Stacking Devices must be followed at all times!
- Manually-created transport units must be correctly stacked and secured!
- Pallets and stacked components are to be protected against the effects of the weather, e.g. secure packed components with tension straps against lifting!
- Always attach the 4-sling lifting gear using the four load-bearing points!


#### Transport


PERI pallets and stacking devices are suitable for lifting by crane or forklift. They can also be moved with the PERI Pallet Lifting Trolley. All pallets and stacking devices can be lifted using both the longitudinal and front sides. The following are some examples.

#### Stacked with Panels SDP 150 x 75

Pallet SD: 48 pieces (Fig. A1.01 + A1.02) Pallet SD: 14 pieces (Fig. A1.04 + A1.05)

The Pallet SD can also be used for storing other SKYDECK components, e.g. Main Beam SLT. (Fig. A1.03)










Lashing straps are manufactured according to DIN EN 12195-2, and are to be regularly checked in accordance with this standard.

#### Stacking:

2 loaded pallets, one on top of the other.







### A1 Storage and transportation



Pallet: Handrail Unit SD 150 Pallet: Handrail Unit SD 75

#### Number of handrail units per pallet

Handrail Unit SD 150: 10 pieces (Fig. A1.06) Handrail Unit SD 75: 10 pieces


(Fig. A1.07)


#### Stacking:

2 loaded pallets, one on top of the other.

#### Loading sequence

- 1. Open locking mechanism on the pallet frame.
- 2. Slide in one handrail unit and close locking mechanism.
- 3. Slide in additional handrail units. Handrail units lock automatically above the red bars.
- 4. Secure handrail units on the front side against sliding out. Insert retaining bar and lock in place.





Due to the powder coating, cleaning requirements are kept to a minimum. Panels and main beams are equipped with self-draining edges. They prevent the side areas from getting dirty and make cleaning easier. (Fig. A1.08)




Fig. A1.08

# **A1 Storage and transportation**



#### **SKYDECK Platforms**

The platforms can be stored in stacks of up to 5 elements.

Weights:

SDB 300 184 kg / piece SDB 225 155 kg / piece SDB 150 108 kg / piece

Stacks of platforms can be lifted with a fork-lift truck using the long side.

(Fig. A1.09)

The stack can be moved with the crane by means of the external crane eyes. (Fig. A1.10)



Ensure the platforms are evenly secured on lorries but not too tightly.




Fig. A1.09




Fig. A1.10

### **A2 System components**




#### **Propheads**


Drophead SFK (1)
Prophead SSK (6)
Combihead SCK (7)
Transition Head SDSK (26)
Transition Head SDFK (27)

The Drophead SFK can be used for all standard situations and allows the removal of main beams and panels while simultaneously supporting the slab.

The Prophead SSK must be used in all starting fields. Prophead SSK and Combihead SCK are used, e.g. for compensations.

Prophead SDSK and Prophead SDFK are used when changing direction.





#### Main beams

- Main Beam SLT 225
- Main Beam SLT 150

For the exclusive use with the SKYDECK Platform SDB, a main beam which can accommodate the Platform SDB is available.

It may only be used for the described purposes.

- Main Beam SLT 375

#### **Panel SDP**


The Panel SDP is available with the following dimensions:

- Panel SDP 150x75
- Panel SDP 150x50
- Panel SDP 150x37.5
- Panel SDP 75x75
- Panel SDP 75x50
- Panel SDP 75x37.5

#### **Cover Strip SAL**

The Cover Strip SAL is available with the following dimensions:

- Cover Strip SAL 150
- Cover Strip SAL 75
- Cover Strip SAL 50
- Cover Strip SAL 37.5






Fig. A2.04

### **A2 System components**



#### Slab props

Dropheads SFK, Propheads SSK, SDFK or Combiheads SCK fit on props with a hole diameter of Ø 38-40 mm. With hole diameters > 40 mm, the heads must be bolted diagonally using 2 Bolts ISO 4016 M12  $\times$  40-4.6 galv., Mu, item no. 035440. (Fig. A2.01)



Transition Heads SDSK (26) must always be bolted: see A9 Changing direction.




Prop loads over 33.3 kN: bolting on of drophead for use with PEP Slab Props using 2 Bolts DIN EN ISO 4016 M12 x 40-4.6 galv., Mu.

#### **Preparing the Drophead**

- 1. Push drophead wedge (1.1) and Drophead (1.2) upwards as far as possible. (Fig. A2.06)
- 2. Insert drophead wedge.
- 3. Secure with hammer blow = shuttering position.
  - $\rightarrow$  Drophead SFK is ready for use.


#### Preparing the slab props

- Adjust the extension lengths of the props. Clear room height minus dimension x (Fig. A2.07). Take into consideration the different overall heights of the main beams: Main Beam SLT 225 = 24 cm / Main Beam SLT 150 = 19 cm.
- 2. Insert the prepared Drophead (1),
  Prophead (6) or Combihead (7) into
  the prop. The self-locking coupling is
  secured automatically. (Fig. A2.01)
  → The prop is ready for use.



#### Starting bay

Main Beam SLT 225



#### Starting bay

Main Beam SLT 150

#### End bay

End bay

Main Beam SLT 225

Panel SDP






Fig. A2.07



### **A2 System components**





### A3 System dimensions




### Notes regarding static calculations


This design information is used for the design and planning of the SKYDECK Slab Formwork System. It covers standard configurations for slab thicknesses from 0.14 m to 1.09 m.

#### Comparison of the design method

# The design concept with partial safety factors



Method of proof



#### Key

 $R_k$  = characteristic resistance

 $R_d$  = design value of the resistance

 $F_k = F_{actual} = actual or characteristic action$ 

 $E_d$  = design value of the action

 $F_{ult.} = R_k = characteristic resistance (e.g. breaking load)$ 

 $F_{perm.}$  = permissible load-bearing capacity

# Design method used in this design information


This design information is based on the design concept with the global safety factor.

The tables of the prop loads include the permissible load-bearing capacities  $F_{\text{perm.}}$ 

After multiplication using  $\gamma_F=1.5$ , the maximum load-bearing capacity can also be converted into a design value of the resistance  $R_d$  for the method with partial safety factors.

# The old design concept with the global safety factor

(see PERI Design Tables)



#### Method of proof

$$\frac{F_{ult.}}{\gamma_{tot.}} \ge F_{actual} (= F_k)$$

$$F_{perm.} \ge F_{actual} (= F_k)$$

 $\gamma_{M}$  = partial safety factor for the material (steel  $\approx 1.1$  / concrete  $\approx 1.5$ )

/F = partial safety factor for the load (permanent = 1.35 / changeable = 1.5)

 $\gamma_{tot.}$  = global safety factor  $\approx \gamma_M \cdot \gamma_F$ (steel  $\approx 1.65$  / concrete  $\approx 2.25$ )

### A3 System dimensions



### Internal forces and rigidity

#### Permissible internal forces and rigidity for the design with single-span girders

Item no.	Designation	perm. M [kNm]	perm. Q [kN]	El [kNm²]
061100 Main Beam SLT 225		16.0	22.0	1198
061160	Main Beam SLT 375	12.6	22.0	1198
061110	Main Beam SLT 150	11.3	18.0	656
061045	Edge Beam SRT-2 150	2.9	8.0	91
061045	Edge Beam SRT-2 turned	2.1	8.0	31
061047	Edge Beam SRT-2 / 27	3.0	8.0	88
061047 Edge Beam SRT-2 / 27 turned		2.1	8.0	28
061049	Filler Timber SPH 150	0.7	2.4	32
061049	Filler Timber SPH turned	0.4	1.7	7
061050 Filler Timber SPH / 27		0.6	2.4	29
061050 Filler Timber SPH / 27 turned		0.3	1.3	7

Table A3.01

#### Load combinations

#### Vertical loads Concreting

(according to DIN EN 12812)

SKYDECK dead load  $O_1 = 0.20 \text{ kN/m}^2$ Concrete load  $O_{2,b} = 24.5 \text{ kN/m}^3 \times \text{d [m]}$ 

Equivalent load concreting  $Q_4 = 0.10 \times Q_{2,b}$ 

 $0.75 \text{ kN/m}^2 \le Q4 \le 1.75 \text{ kN/m}^2$ 

Equivalent load working

conditions  $Q_{2n} = 0.75 \text{ kN/m}^2$ 

Total load  $Q = Q_1 + Q_{2,p} + Q_{4,p}$ 

#### **SKYDECK Platforms SDB**

(according to DIN EN 12811)

Load Class 2  $q_1 = 1.50 \text{ kN/m}^2$ 

 $F_1 = 1.50 \text{ kN } (500 \times 500 \text{ mm}^2)$ 

#### **Horizontal loads**

Horizontal load from working operations = 1% of the vertical load (DIN EN 12812; 8.2.2.2) Horizontal load from the tilting position = 1% of the vertical load (DIN EN 12812; 9.3.4.2)

#### Wind loads

Working wind dynamic pressure  $q_{W,A} = 0.20 \text{ kN/m}^2 \text{ (DIN EN 12811-1; 6.2.7.4.2)}$ 

Maximum wind speed dynamic pressure  $q_{W,max} = 0.60 \text{ kN/m}^2$ 

Height of the substitute area for equipment and materials on the scaffold level LF working wind  $h_{W,A} = 0.40 \text{ m}$  (DIN EN 12811-1, 6.2.7.4.2)

Height of the substitute area for equipment and materials on the scaffold level LF maximum wind speed  $h_{W,max} = 0.20 \text{ m}$  (DIN EN 12811-1, 6.2.7.4.1)

Wind on the side protection

Working wind speed on SKYDECK Guardrail Holder SGH and Guardrail Post SGP

 $q_{W,A,S} = 0.183 \text{ kN/m}$ 

Maximum wind speed with SKYDECK Guardrail Holder SGH and Guardrail Post SGP

 $q_{W,max,S} = 0.550 \text{ kN/m}^2$ 

#### **SKYDECK Paneel Deckenschalung**

# A3 System dimensions



#### Overview of the required frames: MRK with the use of MULTIPROP Towers PRK with the use of PEP Props

Frames	MRK Item no.	PRK Item no.	SKYDECK system
62.5 Steel	028390	111811	<ul><li>Inset beam at wall beginning with 75 cm panel span.</li><li>Inset prop at wall beginning with Combinead.</li></ul>
75 Steel	028400	111812	- Panel span 75 cm.
137.5 Steel	028380	111813	- Inset beam at wall beginning with 150 cm panel span.
150 Steel	028350	111814	- Panel span 150 cm.
201.5 Alu	028460	111815	<ul> <li>Inset prop at wall beginning under SLT 225 with Prophead or Combihead.</li> </ul>
225 Alu	028360	111816	<ul> <li>SLT 225 on Prophead or Combihead.</li> <li>Use of Cantilever Beam SLT 375 on Prophead/Combihead or corner tables.</li> </ul>
230 Alu	028470	111817	- SLT 225 on Dropheads.

Table A3.02




Fig. A3.01 Fig. A3.02



#### Starting bay



# Shuttering using a safe mobile scaffold!

#### Position props and main beams

- 1. Position prop with Prophead (6) in one corner of the room (spacing: see Fig. A4.05).
- 2. Secure with tripod to prevent it from falling over.
- Position prop with Drophead (1). Distance from the wall 2.275 m. (Fig. A4.01)
- 4. Secure with tripod to prevent it from falling over.
- 5. Insert Main Beam SLT 225 (2) into the beam support of the Prophead and Drophead. The main beam connection (2.1) must be mounted in the middle of the beam support (1.2) of the SKYDECK heads. (Fig. A4.02a / A4.02b / A4.02c)
- 6. Secure Main Beam SLT 225 (2) with Wall Holder SWH-2 (8).
- 7. Position second pair of props at a distance of 1.50 m from the wall.
- 8. Insert Main Beam SLT 225 (2) in the beam support. (Fig. A4.02a / A4.02b / A4.02c / A4.04)



Does the main beam connection (2.1) enclose the beam support (1.2)? (Fig. A4.02c)



Set up drophead props on the wall so that the drophead wedge can be removed during striking.

The Main Beam SLT is always positioned parallel to the longer wall side. Always check the rectangularity of the first bay.

#### Components

- 1 Drophead SFK
- 2 Main Beam SLT
- 6 Prophead SSK
- 8 Wall Holder SWH-2




Fig. A4.02b

Fig. A4.02c




Fig. A4.03




Fig. A4.04

**Section A-A** 




Fig. A4.05




Fig. A4.05a



#### **Insert panels**

- 1. Install panels (3) on the Main Beam SLT 225 (2).
  - → The rack of the Main Beam SLT fixes the panel in position.
- 2. Secure wall-side panel and Main Beam SLT with Wall Holder SWH-2 (8). (Fig. A4.06)
- 3. Install two additional panels. (Fig. A4.07)
  - → The starting bay is complete. (Fig. A4.08)



Spray the edge of the panel with release agent before positioning.




Fig. A4.06




Fig. A4.07

### Wall Holder SWH-2



# The formwork surface area may only be accessed or loaded when Wall Holders SWH-2 have been installed!

The Wall Holder SWH-2 (8) is used to hold the slab formwork in a horizontal position during the assembly. It is installed in longitudinal and transverse directions, and can fix the main beam as well as the panel. The Wall Holder SWH-2 (8) is mounted in every second bay.

#### **Assembly**

- 1. Insert tie rod with wingnut pivot plate through the available tie hole.
- 2. Place Main Beam SLT into the Wall Holder SWH-2 or push into the edge of the panel.
- 3. Tighten Wall Holder SWH-2 with Wingnut Pivot Plate on the wall.
- 4. Remove tripods. (Fig. A4.08)

  → The wall holder isassembled.




Fig. A4.08



#### **Transverse bay**

- 1. Position prop with Prophead SSK (6). Spacing 1.50 m.
- 2. Secure with tripod.
- 3. Position prop with Drophead SFK (1). Spacing 2.275 m.
- 4. Insert Main Beam SLT 225 (2) into the beam support of the Prophead and Drophead. (Fig. A4.09)
- 5. Secure with tripod.
- 6. Insert panels (3). (Fig. A4.10)
  - → The transverse bay is complete. (Fig. A4.11)



# Shuttering is carried out using a safe mobile scaffold!



Working in a transverse direction is recommended.

Use tripods again in the next bay.




Fig. A4.09




Fig. A4.10

- 1 Drophead SFK
- 2 Main Beam SLT
- 3 Panel SDP
- 6 Prophead SSK
- 8 Wall Holder SWH-2




Fig. A4.11



### Longitudinal bay



Based on the risk assessment, the contractor must decide whether forming takes place from above or below!

- 1. Attach Main Beam SLT 225 (2) to the Drophead.
- 2. Connect prop with Drophead in the main beam. (Fig. A4.12)
- 3. Place prop in a vertical position. (Fig. A4.12a)
- 4. Secure with tripod.
- 5. Proceed likewise with the second main beam and prop.
- 6. Insert panels (3). (Fig. A4.13)
- 7. Remove tripod and use again in the next bay.
  - → The longitudinal bay is now complete. (Fig. A4.14)




Fig. A4.12





Fig. A4.12a



Optimum angle for mounting the Main Beam SLT up to  $\alpha$  45°.

The main beam is correctly fitted only if the corner of the recess hangs under the prop without obstruction.



The Wall Holder SWH-2 (8) is mounted in every second bay.



#### Risk of falling!

- When lingering on the slab formwork, measures must be taken to prevent falling, e.g. PPE.
- When shuttering from below, use a safe and secure mobile scaffold; install panels overhead.





Fig. A4.13





During forming from above, press panel down with the foot when installing.



If the SKYDECK Guardrail Holder is used, this must be installed during setting of the panels. For details, see Section A8.

- Main Beam SLT 2
- Panel SDP 3
- Cover Strip SAL 4
- Pallet SD 5
- Wall Holder SWH-2 8
- 21 Panel Clip SPK




Fig. A4.14



#### Standard bay

Due to the recurring assembly sequence, always continue in the same way.



With all-round enclosed structure geometries, panels are to be fixed by means of two Panel Clips SPK (21) each time to the main beams for wind speeds between 0.033 kN/m² (26 km/h) and dynamic pressure 0.061 kN/m² (36 km/h). For unfavourable structure geometries or larger wind speeds, additional securing measures are to be implemented, e.g.:

- ballast
- bracing (Fig. A4.16)
- dismantling the formwork etc.
- 1. Attach Main Beam SLT 225 (2) to the Drophead.
- 2. Connect prop with Drophead SFK in the raised main beam. (Fig. A4.15)
- 3. Place prop in a vertical position.
- 4. Insert panels (3).
  - → The standard bay is now complete.




Fig. A4.15




Fig. A4.16




Fig. A4.17

The Prophead SSK is not a substitute for the Drophead.
Without the Drophead, the Cover Strip (4) has no supporting effect.



#### Shuttering the casting segment

Set down Pallet SD (5) with panels (3) onto the forming area. Place panels in the main beams. Make empty pallets available in preparation for the striking process. (Fig. A4.18)

- Shutter the standard fields until there is no more space for the Main Beam SLT 225 or Compensation Beam SLT 150.
- 2. Form the infill areas. See A5.
- 3. Continually insert Cover Strip SAL (4). (Fig. A4.19)
- 4. Thinly spray the forming area with a release agent also from below if used for the first time.




Fig. A4.18



#### Risk of slipping!

The forming area becomes slippery through the use of release agents!

- Be extremely careful when accessing forming areas after spraying!
- Weather conditions are to be taken into account!




Fig. A4.19



Regarding the tightness of the panel joints, e.g. for casting segments/setting of stopends, push the panels tightly together and secure on the last main beam with Panel Wedge Clips SPKK (20)

(Fig. A4.20 - Fig. A4.22)

#### Panel Wedge Clip SPKK

The panel wedge clip is used to connect 2 panels with one main beam.

#### Possible applications

1. Panel joint in the middle of main beam




Fig. A4.20




Fig. A4.21




Fig. A4.22

Side view

#### SKYDECK Panel Slab Formwork





#### System components

For the realization of compensations and shuttering of columns, a range of system components is available.



#### Secure filler plates with nails!

#### Edge Beam SRT 150-2, **SRT 75**

Install vertically (Fig. A5.01) or suspended. (Fig. A5.02) The locking pin (9.1/10.1) secures the Edge Beam SRT 150 (9) or SRT 75 (10):

- to the Main Beam SLT in a longitudinal direction. (Fig. A5.01 + A5.02)
- to the Prophead SSK in a transverse direction. (Fig. A5.03)
- to the Combihead SCK (7) in a longitudinal direction. (Fig. A5.04)
- in the End Support SSL (11) in a longitudinal direction. (Fig. A5.07)

#### Filler Timber SPH

Install Filler Timber SPH (12) vertically or horizontally.

- to the Combinead SCK. (Fig. A5.04)
- nailed laterally on the panel.
- horizontally, transverse to the suspended Edge Beam SRT. (Fig. A5.05 + A5.06)

### **End Support SSL**

Use the End Support SSL as height adjustment for the transition from a standard bay to an infill area.

(Fig. A5.07)

The End Support SSL must always be directly supported by means of a Prophead, Drophead or Combinead. (Fig. A5.08)

- Main Beam SLT
- Panel SDP 3
- Combinead SCK 7
- Edge Beam SRT-2 150
- Edge Beam SRT-2 150, suspended
- Edge Beam SRT-2 75
- 10\* Edge Beam SRT-2 75, suspended
- **End Support SSL**
- 12 Filler Timber SPH





Fig. A5.01



The asterisk (\*) refers to the installation in a suspended position.




Fig. A5.03




Fig. A5.04




Fig. A5.05





Fig. A5.06






Fig. A5.08




Fig. A5.09



No End Support SSL without any direct support through Prophead, Drophead or Combinead.




#### Combinead SCK

Use of longitudinal and transverse infills up to 25 cm.

The cantilever of the Head Plate is in longitudinal direction  $\leq$  19 cm, in transverse direction  $\leq$  12.5 cm.

The Combinead (7) (Fig. A5.11) is a secure, non-movable and non-twisting support for:

- Main Beam SLT 225 (2).
- SLT 150 (2.5). (Fig. A5.10)
- Panel SDP (3). (Fig. A5.12)
- Edge Beam SRT (9) and Filler Timber SPH (12) or timber provided by the contractor with b = 3.8 - 8 cm and h = 9.8 cm. (Fig. A5.13)
- End Support SSL (11). (Fig. A5.14)



The Main Beam SLT must be mounted in the middle of the beam support of the SKYDECK Heads. The main beam connection (2.1) encloses the main beam support (7.1) of the head. (Fig. A5.10)

The Combinead SCK has 2 main beam supports and can be installed in both directions. In infill areas, the cantilever points towards the compensation.

#### **Exceptions:**

The cantilever points towards the main

- when using the End Support, (Fig. A5.14)
- when infill ≤ cantilever. (Fig. A5.14a)

#### Placing the main beam

With inset props, the cantilever of the Combinead always points towards the main beam.

Position the Combihead so that the main beam support is securely positioned in the groove (2.8) of the main beam.

(Fig. A5.15)




Fig. A5.10




Fig. A5.11




Fig. A5.12




Fig. A5.13




Fig. A5.14





Fig. A5.14a





#### **Insert panels**

With direct panel support, install the cantilever of the Combinead in the direction of the infill area. (Fig. A5.16)

The teeth in the plastic racks (7.2) on the cantilever hold the panels (3) in 5 different positions. Select support position according to the compensation width. Position the cantilever of the Combinead SCK as close as possible to the wall in order to provide maximum support for the infill area. (Fig. A5.17c – A5.17d)




Fig. A5.16




Fig. A5.17




Fig. A5.17a




Fig. A5.17b




Fig. A5.17c




Fig. A5.17d



Do not install panels in a longitudinal direction outside of the longitudinal axis of the Combihead.

(Fig. A5.17e + A5.17f)

- 1 Drophead SFK
- 2 Main Beam SLT
- 3 Panel SDP
- 7 Combinead SCK
- 14 Triangular Frame SDR




Fig. A5.17e






Fig. A5.17f










Fig. A5.18 Fig. A5.18a Fig. A5.18b



With a transverse positioned Combihead, e.g. in compensation areas, place panels at least as far as the central axis or further!

In corners where longitudinal and transverse compensations meet, the Combihead (7) is aligned in the direction of the main beam. (Fig. A5.19 A)

Install the cantilever of the Combihead (7) up to the compensation area. (Fig. A5.19 B)

In the system with the Drophead (1), the Combihead (7) is always installed transversely if it is positioned under a cover strip. As a result, the panels are prevented from slipping out of position. (Fig. A5.19 C)




Fig. A5.19



# Triangular Frame SDR 150/75, 75/75

Form infill areas with inclined walls using triangular frames.

#### Forming the infills

- 1. Continue forming in the system as long as possible.
- Carry on forming operations with filler panels as well as transversely inserted panels – as for longitudinal and transverse compensations.
- 3. Lay Triangular Frame (14) on the support (Main Beam, Prophead or Combihead, End Support). (Fig. A5.20)
- 4. Place the support on the wall side.
- 5. Install formlining and secure in position with nails.




Fig. A5.20

### **Longitudinal compensations**



#### Secure filler plates with nails!

# Drophead infills up to 2.25 m + 5 cm. Prophead infills up to 2.25 m.

Length of room minus n x 2.30 m (2.25 m) = compensation area. See Tables: Fillers / Forming around columns.

### Forming longitudinal compensations between 75 cm and 2.25 m

- 1. Continue forming with prop, Compensation Beam SLT 150 (2.5) and Panel SDP (3) as in the standard bay. (Fig. A5.21)
- Depending on the required load-bearing capacity, continue forming with filler panels. See PERI Tables.
- 3. Forming of gaps up to 75 cm, see following pages.




Fig. A5.21



- Take into account the load-bearing capacity and supporting direction of the formlining. See PERI Tables.
- Timbers are securely nailed on the panel inner side before panels are assembled. Use the nail holes in the panel edge struts.



0 - 6

#### Gap 0 - 6 cm

- 1. Place Combihead SCK (7) or Prophead SSK (6) in a recessed position under the Main Beam SLT (2.5).
- 2. Nail Filler Timber SPH (12) or timber up to max. 6 cm on the panel.
- 3. Install formlining (16) and secure with nails. (Fig. A5.22 + A5.23)




Fig. A5.22





Fig. A5.23

#### Gap 5 - 12.5 cm

- 1. Place Main Beam SLT (2) on inset prop with Combinead SCK (7) or Prophead SSK (6).
- 2. Place additional props with transversely positioned Combiheads SCK (7a) in an offset arrangement.
- 3. Install Filler Timber SPH (12) or Edge Beam SRT (9).
- 4. Position the formlining and secure with nails. (Fig. A5.24 + A5.25)







Fig. A5.25

- Drophead SFK
- 2.5 Main Beam SLT 150
- Panel SDP 3
- 6 Prophead SSK
- 7 Combinead SCK
- Edge Beam SRT-2 150 9
- 11 End Support SSL
- 12 Filler Timber SPH
- 13 Timber
- 14 Triangular Frame
- 15 Additional prop with crosshead and formwork girder
- 16 21 mm formlining provided by the contractor



#### Gap 12.5 - 20 cm

- 1. Mount Combinead SCK turned by 180° (7) or Prophead SSK in the main beam support.
- 2. Install End Support, Filler Timber and Edge Beam.
- 3. Install formlining and secure in position with nails. (Fig. A5.26 + A5.27)






Fig. A5.26

#### Gap 20 - 75 cm

- Install Main Beam in Drophead SFK (1) (Fig. A5.31), with 180° turned Combihead SCK (7) (Fig. A5.32) or Prophead SSK (6) (Fig. A5.33).
- 2. Mount End Support (11) and Edge Beam (9).
- 3. Position additional prop with crosshead and formwork girder (15).
- 4. Install formlining and secure in position with nails. (Fig. A5.28 A5.30)




Fig. A5.27

Fig. A5.28




Fig. A5.29




Fig. A5.30

Instructions for Assembly and Use – Standard Configuration




#### **Transverse compensations**



#### Secure filler plates with nails!

Max. infills are 1.50 m. Infills are calculated based on length of  $room - n \times 1.50$  m.

See Tables: Fillers / Forming around columns.



### Transverse infill between 75 cm and 1.50 m

- 1. Continue forming with prop, Main Beam SLT 225 (2) and transversely-positioned panel (3). Close the spacing to the next prophead with Panel SDP 75 x 75 (3a). (Fig. A5.31 + A5.32)
- 2. Depending on the required load-bearing capacity, continue forming with filler panels. See PERI Tables.
- 3. Form gaps up to 75 cm; see following pages.



- Take into account the load-bearing capacity and supporting direction of the formlining. See PERI Tables.
- Timbers are securely nailed or screwed on the panel inner side before panels are assembled. Use the nail holes in the panel edge struts.

- 1 Drophead SFK
- 3 Panel SDP
- 6 Prophead SSK
- 7 Combinead SCK
- 9 Edge Beam SRT-2 150
- 11 End Support SSL
- 12 Filler Timber SPH
- **15** Additional prop with crosshead and formwork girder
- **16** 21 mm formlining provided by the contractor




Fig. A5.31




Fig. A5.32



0 – 12


#### Gap 0 - 12 cm

- 1. Place Panel SDP (3) over the Main Beam SLT (2) and secure with Panel Wedge Clips (20). (Fig. A5.33 – A5.35)
- Nail Filler Timber SPH (12) or timber (13) up to max. 6 cm on the panel.
   (Fig. A5.35) Screw Filler Timber SPH (12) or timber (13) up to max. 6 cm on the panel. (Fig. A5.36)
- 3. Install formlining (16) and secure with



If panels (3) are placed over the main beam (2), the panel edge can not laterally stabilize the main beam.

→ Secure every main beam with a Panel Wedge Clip SPKK to prevent overturning!






Fig. A5.33 Fig. A5.34




Fig. A5.35

#### Gap 5 - 12.5 cm

- 1. Position Combinead SCK (7) with cantilever in the direction of the infill.
- 2. Install Panel (3).
- Install Edge Beam SRT-2 (9) or Filler Timber SPH (12) in the Combihead (7).
- 4. Install formlining (16) and secure with nails. (Fig. A5.36)




Fig. A5.36



12 - 24

#### Gap 12.5 - 25 cm


- 1. Position Combinead SCK (7) with cantilever in the direction of the infill.
- 2. Install Panel (3).
- 3. Install Edge Beam SRT-2 (9) or Filler Timber SPH (12) in the Combinead.
- 4. Install formlining (16) and secure with nails. (Fig. A5.37)

#### **Alternatively**

- 1. Place Panel SDP (3) over the Main Beam SLT (2) and secure with Panel Wedge Clip (20).
- 2. Screw Filler Timber SPH (12) or timber on the panel.
- 3. Position additional prop with crosshead (15) and formwork girder.
- 4. Install formlining (16) and secure with nails. (Fig. A5.38)

#### Gap 25 - 75 cm

- 1. Mount the Panel SDP (3) in the Main Beam (2).
- 2. Insert Edge Beam SRT-2 (9) in the Main Beam.
- 3. Position additional prop with crosshead (15) and formwork girder.
- 4. Install formlining (16) and secure with nails. (Fig. A5.39 + A5.40)








Fig. A5.37 Fig. A5.38





- Drophead SFK Main Beam SLT 2
- Panel SDP 3

- 6 Prophead SSK
- 7 Combinead SCK
- 9 Edge Beam SRT-2 150
- 12 Filler Timber SPH
- 13 Timber
- 15 Additional prop with crosshead and formwork girder
- **16** Formlining
- 20 Panel Wedge Clip SPKK

Fig. A5.40

### A6 Shuttering around columns



#### 1 recessed panel

Maximum column dimensions x = 55 cm, y = 138 cm.



#### Secure filler plates with nails!

Install Edge Beam SRT-2 150 vertically (9) or Filler Timber SPH 150 (12). During use, permissible loads must be observed; see Tables: Fillers / Forming around columns



Take into account the supporting direction of the formlining.


#### Alternatively:

Install Edge Beam SRT-2 150 (9\*) in a suspended position. (Fig. A6.03) Flatly position Filler Timber SPH or install timber (13) supplied by the contractor.

For 27 mm formlining: height of timber = 47 mm.

Permissible widths of influence for flat Filler Timber SPH, see Table A6.02.

- 9 Edge Beam SRT-2 150
- **10** Edge Beam SRT-2 75
- 9\* Edge Beam SRT 150, suspended
- 10\* Edge Beam SRT 75, suspended
- 12 Filler Timber SPH
- 13 Timber







Fig. A6.02

Fig. A6.03



# A6 Shuttering around columns



# 2 recessed panels


Maximum column dimensions x = 65 cm, y = 138 cm.



# Secure filler plates with nails!

Install Edge Beam SRT 150 (9) vertically at the panel edge. Insert Edge Beam SRT 150 (9\*) in a suspended position at the column.

Likewise, insert Edge Beam SRT 75 (10\*) in the Edge Beam (9\*) in a suspended position. (Fig. A6.05 + A6.06)






Fig. A6.06

Maximum column dimensions x = 130 cm, y = 138 cm.


Depending on the slab thickness and prop width, the transverse-positioned filler plates are to be additionally supported, see Table A6.02.

Insert Edge Beam SRT-2 150 (9\*) in a suspended position. Lay Filler Timber SPH 150 (12) in a flat position. Permissible widths of influence for flat Filler Timber SPH, see Table A6.02 on next page. (Fig. A6.07 + A6.08)

With smaller cross-sections, form infill areas with Panel SDP 37.5.



Take into account the supporting direction of the formlining.






Fig. A6.08

# A6 Shuttering around columns



# 3 recessed panels

Maximum column dimensions x = 138 cm, y = 142 cm.



# Secure filler plates with nails!

Install Edge Beam SRT-2 150 (9) vertically, Edge Beam SRT-2 150 (9\*) suspended, Filler Timber SPH 150 (12) horizontally. (Fig. A6.09, Fig. A6.10)




Fig. A6.10

# Additional Edge Beam SRT-2 150 (9) required with:

Slab thickness d [m]	Column side y [m]
≤ 0.20	no additional SRT
0.25	≤ 0.40
0.30	≤ 0.70
0.40	≤ 1.15

Table A6.01

For other slab thicknesses, the values are interpolated linearly.



Take into account the supporting direction of the formlining.

# Permissible width of influence of flat Filler Timber SPH, maximum deformation I/500

	permissible width of influence Filler Timber SPH flat e $_{\mathrm{SPH,flat}}$ [cm]							
	with span L <sub>SPH</sub> [cm]							
Slab thickness	100	80	60					
14	30	58	137					
16	26	51	121					
18	23	46	108					
20	21	41	98					
22	19	38	89					
24	18	35	82					
25	17	33	79					
26	16	32	76					
28	15	30	71					
30	14	28	66					
35	12	24	57					
40	11	21	50					
43	10	20	46					

Table A6.02

# A6 Shuttering around columns



### Recessed main beams




Secure filler plates with nails! Secure props of the Edge Beam SRT (\*\*) with tripod!

# Components

- 9 Edge Beam SRT-2 150
- 6 Prophead SSK
- 11 End Support SSL

Only used if moving the main beam axis is not desired. (Fig. A6.11, Fig. A6.12)

Additional formlining support depending on the situation on site.






Fig. A6.12

Secure props by means of tripod.

# **Shifting the main beam axis** (Fig. A6.13)



# Secure Main Beam SLT (\*\*) props that have been shifted with tripods!

In the area of the box out, screw timber (13) on the panel as filler support.



Take into account the supporting direction of the formlining.

- 6 Prophead SSK
- 9 Edge Beam SRT-2 150
- 9\* Edge Beam SRT 150, suspended
- 10 Edge Beam SRT-2 75
- 11 End Support SSL
- 12 Filler Timber SPH
- 13 Timber




Fig. A6.13



# Transfer of horizontal loads into the columns of the building

The horizontal loads according to DIN EN 12812 are to be accommodated by the building walls, columns or bracings. SKYDECK is able to transfer these loads into the building columns according to Table A7.01 without requiring any additional bracing.

The prerequisite is that the building columns can accommodate the horizontal loads according to the table.

At the edge of the slab, corresponding loads, e.g. from the stopend formwork pressure, platforms or wind, must be separately anchored.



With a rectangular column grid, the largest column spacing is decisive.

Slab thickness	Panel span	Maximum perm. column grid (building columns)	Horizontal load per column (building column)
[cm]	[cm]	a [m]	H [kN]
14	150	10.31	9.44
16	150	9.26	8.48
18	150	8.39	7.69
20	150	7.68	7.03
22	150	7.07	6.48
24	150	6.56	6.00
25	150	6.32	5.79
26	150	6.11	5.59
28	150	5.71	5.23
30	150	5.37	4.92
35	150	4.63	4.24
40	150	4.06	3.72
43	150	3.77	3.45
45	75	3.59	3.29
50	75	3.21	2.94
55	75	2.90	2.66
60	75	2.68	2.45
65	75	2.48	2.27
70	75	2.31	2.12
75	75	2.17	1.99
80	75	2.05	1.88
85	75	1.95	1.78
90	75	1.85	1.70

Table A7.01

### Example

Slab thickness 30 cm, panel span 150 cm.

- → permissible column grid without bracing the SKYDECK: = 5.37 m (a).
- → Horizontal load to be transferred: H = 4.92 kN.

This load must be verified by the structural engineer regarding the respective column in the actual building condition. (Fig. A7.01)




Fig. A7.01



### General



- Do not access the forming area before the formwork has been horizontally anchored!
- Do not access the cantilevers before the bracing has been mounted in a form-fitting manner!

Formwork positioned on open building edges or concreting sections, is to be secured against horizontal loads by means of bracing.

Cantilevers, e.g. on edge bay, must be additionally vertically braced in order to prevent any tilting.

Example calculation: see Transfer of horizontal loads from a casting segment.




Fig. A7.02

# Bracing of the inner bay

- Maintain spacings
- Bays must be braced longitudinally and horizontally

### **Assembly**

- Mount Base Plate on a sufficiently load-bearing surface area, e.g. using PERI Anchor Bolt 14/20x130, Item no. 124777. Take into consideration the Technical Data Sheet!
- 2. Attach Anchor Chain to the panels:
  - In the longitudinal direction, attach Anchor Chain (23) to the Tension Sleeve SAO (39). (Fig. A7.03)
  - In the transverse direction, connect panels to scaffold tube (31). Wrap Chain (23) around the scaffold tube. (Fig. A7.03a)
- 3. Secure Anchor Chain to Base Plate using bolts, and secure bolts by means of cotter pins. (Fig. A7.03b)

# Longitudinal direction




Fig. A7.03

### Lateral direction




Fig. A7.03a

- 23 Anchor Chain (permissible tension force = 3 kN)
- 24 Base Plate RS
- **24.1** Anchor Bolt PERI 14/20 x 130
- 31 Scaffold Tube
- 39 Tension Sleeve SAO




Fig. A7.03b



# Transfer of horizontal loads from a casting segment

# Example 1

# Open building edge on one side

Bracing in one building direction. (Fig. A7.05)

Values: see Table A14.01.

# Requirements

- Load Case Combination LFK 1: Concreting
- Load Case Combination LFK 2: Storm
- Slab thickness d = 25 cm
- Panel span = 1.50 m
- 1 edge area
- 9 inner bays

### **Number of chains**

- The load case combination which results in the biggest value is decisive.
- Permissible horizontal component of the tension load on the anchor chain
   3 kN x cos 60° = 1.5 kN. (Fig. A7.04)

### Calculation

# **Load Compilation LFK 1 Concreting**

1 x  $H_{load}$  edge area + 9 x  $H_{load}$  inner bay =  $\Sigma H$ 2.447 kN + (9 x 0.54 kN) = 7.307 kN

### **Load Compilation LFK 2 Storm**

 $1 \times H_{load}$  edge area  $+ 9 \times H_{load}$  inner bay  $= \sum H$ 1.291 kN  $+ (9 \times 0.033 \text{ kN}) = 1.588 \text{ kN}$ 

### **Number of chains**

 $\Sigma$ H = 1.588 kN < 7.307 kN LFK 1 Concreting is decisive

 $n_{chain} = \sum H / perm.$  tension force of chain

= 7.31 kN : 1.5 kN = 4.87 chains = **5 chains** 



Fig. A7.04





Fig. A7.05



		Load	Horizontal Lo	ad <sub>edge area</sub> [kN]	Load Case	Load Case Combination LFK 1: Concreting*				Load Case Combination LFK 2: Storm**			
Slab	according	c = 1.50 m	c = 0.75 m	Horizontal Lo	ad <sub>inner bay</sub> [kN]	Horizontal Lo	ad <sub>edge area</sub> [kN]	Horizontal Lo	ad <sub>inner bay</sub> [kN]	Horizontal Lo	ad <sub>edge area</sub> [kN]		
thic	kness	to DIN	from	from									
[6	cm]	EN 12812	stopend		Panel span								
		[kN/m²]	formwork	formwork	c = 1.50  m	c = 0.75  m	c = 1.50  m	c = 0.75  m	c = 1.50  m	c = 0.75  m	c = 1.50  m	c = 0.75 m	
			pressure	pressure									
	25	7.83	1.430	0.715	0.540	0.270	2.447	1.224	0.033	0.016	1.291	0.645	

Excerpt from Table A14.01



# Example 2:

# Open building edge on both sides

Bracing in both building directions. (Fig. A7.08) Values: see Table A14.01.

# Requirements

- Load Case Combination LFK 1: Concreting
- Load Case Combination LFK 2: Storm
- Slab thickness d = 25 cm
- Panel span = 1.50 m
- 2 edge areas
- 8 inner bays

### **Number of chains**

- The load case combination which results in the biggest value is decisive.
- Permissible horizontal component of the tension load on the anchor chain
   3 kN x cos 60° = 1.5 kN. (Fig. A7.04)

### Calculation

# **Load Compilation LFK 1 Concreting**

 $2 \times (H_{load} \text{ edge area - stopendformwork pressure*})$  +  $(8 \times H_{load} \text{ inner bay})$  =  $\Sigma H$ 2 × (2.447 kN - 1.43 kN) +  $(8 \times 0.54 \text{ kN})$  = 6.354 kN

# **Load Compilation LFK 2 Storm**

 $2 \times H_{load}$  edge area  $+ (8 \times H_{load} \text{ inner bay}) = \sum H$  $2 \times 1.291 \text{ kN}$   $+ (8 \times 0.033 \text{ kN})$  = 2.846 kN

### **Number of chains**

 $\Sigma$ H = 2.846 kN < 6.354 kN LFK 1 Concreting is decisive

 $n_{chain} = \sum H / perm.$  tension force of chain

= 6.54 kN : 1.5 kN = 4.236 chains = **5 chains per load direction** 



Fig. A7.04





Fig. A7.07





\*The stopend formwork pressure is already included in Load Case Combination LFK 1 for edge areas. Through reciprocal elimination on both sides of the open building edge, this value must be deducted from both sides.

# A8 Cantilevers, Guardrails



# Bracing on open building edges to prevent tipping



Horizontal loads must be additionally taken into consideration and transferred, e.g. with bracing; see Section A7.

### **Cantilevers with Panels SDP**

Mount Tension Sleeve SAO (39) on main beam. Distance to inner prop max. 50 cm. Brace using Anchor Chain (23), Base Plate (24) and Anchor Bolt (24.1). (Fig. A8.01)

Max. slab overhang: 37.5 cm.

# Cantilevers with SKYDECK Platforms SDB

(Fig. A8.02 + A8.03) See Cantilevers with Panels SDP.

### Corner table:

The Main Beams SLT "A + B" receive 2-fold horizontal load from the wind and 1-fold load from the stopend formwork pressure. Additional bracing is required.



Fig. A8.03 shows only bracing from Load Case Tilting. Take into account Section A9 SKYDECK Platforms!




Fig. A8.01





Fig. A8.02

- Anchor Chain (permissible tension force = 3 kN)
- 24 Base Plate RS
- **24.1** Anchor Bolt PERI 14/20 x 130
- **39** Tension Sleeve SAO
- 45 SKYDECK Platform SDK



# A8 Cantilevers, Guardrails



# **Guardrails with Handrail Unit SD**

- SD 75
- SD 150

The SKYDECK Handrail Unit SD secures site personnel working on a casting segment against falling in the main field direction.



# Risk of falling! **During assembly of the Handrail** Unit, measures must be taken to prevent falling, e.g. PPE!

# **Assembly**



A free length of at least 35 cm must be available on the main beam in order to be able to mount a Handrail Unit SD. (Fig. A8.04a)


- 1. Pull lug (25.1) upwards. (Fig. A8.07)
- 2. Move the Handrail Unit SD (25) firstly in the direction of the building edge (I.) and then downwards (II.) (Fig. A8.04a)
- 3. Place Handrail Unit SD with the hooks (25.2) between the two teeth (2.2) which are free on the main beam.
  - → The lug falls downwards. Hooks engage and are secured. If the lug is not completely down, then press lug (25.1) downwards by stepping on it. (Fig. A8.05) The Handrail Unit is installed. (Fig. A8.06)



- Is the lug completely folded down?
- Do the hooks enclose the teeth of the main beam? (Fig. A8.05)

# Dismantling

- 1. Pull lug (25.1) upwards. (Fig. A8.07) → Hooks are released.
- 2. Lift out Handrail Unit SD (25) and place in Pallet Handrail Unit SD 150 x 75.







Fig. A8.04a



25.2 25.1 Fig. A8.06 Fig. A8.07

Fig. A8.06a

# A8 Cantilevers, Guardrails



# SKYDECK Guardrail Holder SGH and Guardrail Post SGP




Risk of falling! During assembly, measures must be taken to prevent falling, e.g. PPE!

### **Assembly**

Continuous mounting of Guardrail Holder SGH (17) between the panels. To do so, place the guardrail holder laterally offset on the main beam and slide in. Spacing max. 1.55 m.



Wind safeguard measure: with wind speeds > 90 km/h, remove the top guardrail board. Adapt working area accordingly to suit changed guardrail situation.



- Start with the guardrail holder on the outer right-hand side (17.1) – as viewed when standing in front of the formwork. Mounting bar is pointing to the left.
- 2. Mount all other guardrail holders (17) with the mounting bar pointing to the right. (Fig. A8.09) The mounting bars overlap in the first bay.
- 3. Insert guardrail posts (18).
- 4. Insert guardrail boards and secure with nails. (Fig. A8.10)

- 17 Guardrail Holder SGH
- 18 Guardrail Post SPG
- 20 Panel Wedge Clip SPKK




Fig. A8.09




Fig. A8.10





# **Overview**

The SKYDCK Platform SDB is a prefabricated, foldable scaffold platform for use as working scaffold following DIN EN 12811, Load Class 2, with a permissible load of 1.5 kN/m² (150 kg/m²). It secures the open building edges of the SKYDECK slab formwork.

Assembly of the slab formwork in connection with SKYDECK Platform SDB is carried out in four areas. (I – IV) The sequence must be maintained. (Fig. A9.01)



### Risk of falling!

- Ensure that end-to-end side protection is installed on slabs that have been completed!
- Cantilevers should not have formwork erected or be stepped on before being firmly secured with tension chains.
- Work to be carried out by qualified personnel only!



When using SKYDECK platforms, no safety scaffold is required for the levels below.






Fig. A9.01



# Corner table (Area I)



# Risk of falling! Ensure that end-to-end side protection is installed on slabs that have

Begin forming operations on a free building corner.

The corner table is assembled on the previously concreted slab in the inside of the building. Subsequently, position in the corner (Area I) and secure against tipping. (Fig. A9.01)


# Frame assembly


been completed!

- 1. Spindle out the MULTIPROP Props MP (35) 3 cm on a narrow side. The two props opposite (35.1) are not spindled out. As a result, the height difference resulting from the different installations of the main beam is compensated. The exact height adjustment takes place later.
- 2. Four MULTIPROP Props are placed in a 1.50 m x 2.25 m grid with the spindles (inner tube) downwards and formed into a base frame using MULTIPROP MRK 150 (36) and MRK 225 (36.1) Frames. (Fig. A9.02) Mount the frame at the same level above the slab. Locking wedges (36.2) are facing outwards.
- 3. Attach two Propheads SSK (6) on the extended props.


### Assembly of the main beams

- 1. Insert each Main Beam SLT 375 into a main beam groove:
  - Use two Bolts M12 x 140 DIN 6914 for fixing timbers 8/12.
  - 2 x Table Connector STV (38).
  - Sequence and alignment of bolts and table connectors: see Fig. A9.03.
- 2. Mount Main Beam SLT 375 (2.6) and set the beam down on the front prop.
- 3. Push the Table Connector STV up to the MULTIPROP Props and make a secure connection by tightening the ring bolts. (Fig. A9.03a)





Main Beam Support SSK (shown without table




- 2.6 Main Beam SLT 375
- 6 Prophead SSK
- 35 MULTIPROP Prop MP
- 36 MULTIPROP Frame MRK
- **37** Bolt M12 x 140
- 38 Table Connector STV



- 4. Insert two SAO Tension Sleeves approx. 1 m in each of the grooves of 3 Main Beams SLT 375. Tension sleeves later lie between the two bottom main beams.
- 5. Position Main Beams SLT 375 (2.6) transversely with 1.50 m spacings on the already assembled main beams. At the rear, all three beams have an overhang of 37.5 cm. The first beam is laterally inset 37.5 cm on the lower beam.
- Insert additional Tension Sleeves SAO
   (39) on both sides as far as the bottom main beams. Push the previously mounted tension sleeves inwards against the bottom main beams.

   (Fig. A9.04a)
- 7. Connect the beams together by tightening the tension sleeves.



Timbers are required for load distribution when directly reaching under with the transportation fork.


- 1. Attach 2 timbers with min. 8/12/225 (40) (supplied by contractor) to the hex. bolts using nuts and washers. (Fig. A9.04)
- 2. Diagonally brace the timbers.




The first row of panels (3) is moved 37.5 cm and begins in the centre aligned to the first bottom main beams.

- 1. Insert the SDP 150 x 75 panels from below and secure to the main beams with two SPK Panel Clamps per panel.
- The middle panels are additionally fixed to the front outer panels using two Panel Wedge Clamps SPKK each.
- 3. On the side cantilevered slab edge: install the Guardrail Holder SGH.
- 4. Mount Guardrail Posts SGP and handrail boards as anti-fall protection. (Fig. A9.05)

- 2.6 Main Beam SLT 375
- 17 Guardrail Holder SGH
- 20 Panel Wedge Clip SPKK
- 21 Panel Clip SPK
- **37** Bolt M12 x 140
- 39 Tension Sleeve SAO
- 40 Timber







# Supporting the top main beams

- Insert Table Connector STV into the longitudinal grooves of the top main beams (2.6) which are later positioned in the building.
- 2. Fix 2 MULTIPROP Props MP (35) 1.50 m from the cantilevered girder end using the Table Connector STV (38).
- 3. Brace the MULTIPROP Props MP with MULTIPROP Frame MRK 150 (36)
- 4. Connect the Frames MRK 150 to the Frames MRK 225 (36.1) with at least one scaffold tube L = 2.25 m (31) and three scaffold couplings. (Fig. A9.06)
- 5. Mount the inner SKYDECK Platform SDB (45). (Fig. A9.06a)
- 6. Insert Panels SDP.





# Follow Instructions for Use, SKYDECK Lifting Fork!

- Raise the corner table using the SKYDECK Transportation Fork and extend the Props MP to the required length.
- Position the corner table at the corner of the building so that the front MULTIPROP Props MP (35) are as close as possible to the edge of the building. (Fig. A9.06a)





# Risk of falling!

- Do not erect formwork or step on corner table before the tension chains are securely fixed.
- Do not close the filler areas until the corner table has been securely fixed and SKYDECK platforms have been attached.



- 2.6 Main Beam SLT 375
- 31 Scaffold Tube
- 35 MULTIPROP Prop MP
- 36 MULTIPROP Frame MRK
- 38 Table Connector STV
- **45** SKYDECK Platform SDK







### Tensioning the corner tables




Use anchor chains for securing the tables to the floor.


- 1. Attach one tension chain (23) to the outer Table Connector STV (38) on each of the bottom Main Beams SLT 375, and diagonally tension.
- Attach one tension chain (23.1) to the Tension Sleeve SAO to the first top and inner-positioned Main Beam SLT 375, and diagonally tension.
- 3. On the middle, top main beam, attach two tension chains to the Tension Sleeves SAO. Diagonally (23.2) tension the first tension chain; the second tension chain (23.3) is vertically tensioned. (Fig. A9.07 + A9.07a)



# Risk of falling! During assembly, measures must be taken to prevent falling, e.g. PPE!

- 4. Mount the SKYDECK Platform SDB (45): see A9 Platform installation.
- 5. Close the filler areas: see A5 Compensations and A6 Shuttering of columns.





- 23 Tension chain
- 38 Table Connector STV
- 45 SKYDECK Platform SDK



# Cantilevers (Area II)




### Risk of falling!

- Ensure that end-to-end side protection is installed on slabs that have been completed!
- Do not erect formwork or step on cantilevered tables before the tension chains are securely fixed.

Continue forming after erecting the corner table (Area I) in Area II with main beams. Main beams are laid parallel to the upper beams of the corner table. Start shuttering at the edge of the slab.

- 1. Place prop with Drophead SFK (1) at slab edge and secure with tripod.
- Connect Main Beam SLT 375 (2.6) and support by means of a second prop with Prophead SSK (6) after 2.275 m at the edge of the building. (Formed exclusively with prophead; position front prop at a distance of 2.25 m).
- 3. Mount Tension Sleeve SAO (39) in the main beam groove. Distance ≤ 50 cm from the non-cantilevered end.
- 4. Attach tension chain (23) with turnbuckle to the eye at the top, and anchor to the ground by means of a base plate (24). (Fig. A9.08)
- 5. From below, bay by bay immediately install 3 Panels 150 x 75 (3) and 1 Filler Panel 150 x 37.5 (3a) as far as the platform support (2.7) of the Main Beam SLT 375. For example, with the PERI Stripping Cart ASW 465.



\*with the installation of Frames MRK 230 or MRK 225: turn the Prophead SSK by 45°.






Fig. A9.09



- Depending on the thickness of the slab, position additional props and girders at corresponding distances.
- In those areas where the 1.50 m grid is interrupted by columns etc., a 75 cm bay may be installed. Tension Sleeves SAO are used to secure against tipping.



- Are the props in line with the props of the corner table? (Fig. A9.08)
- Is the Main Beam SLT mounted centrally in the beam support of the heads? Does the main beam connection enclose the main beam support of the head? (Fig. A9.09)

- 1 Drophead SFK
- 2.6 Main Beam SLT 375
- 2.7 Platform Support
- **3** Panel SDP 150 x 75
- **3a** Panel SDP 150 x 37.5
- 6 Prophead SSK
- 10 Edge Beam SRT
- 19 Timber
- 20 Panel Wedge Clip SPKK
- 23 Tension chain
- 24 Base Plate RS
- 39 Tension Sleeve SAO



# Open edge areas (Area III)

Start shuttering on structural constraint points (e.g. wall, casting segment) and work towards the corner table, Area II.

# Slab area (Area IV)

When all edge areas are formed, the slab surface Area IV is formed in the usual way with SKYDECK.



Regarding the tightness of the panel joints, e.g. for casting segments/setting of stopends, push the panels tightly together and secure on the last main beam with Panel Wedge Clips SPKK (20).

### Components

- 2 Main Beam SLT 225
- 2.6 Main Beam SLT 375
- 10 Edge Beam SRT
- **19** Timber
- 20 Panel Wedge Clip SPKK
- 45 SKYDECK Platform SDB 300
- 46 SKYDECK Platform SDB 150
- 47 SKYDECK Platform SDB 225

# Infill areas



# Risk of falling!

- Do not erect formwork or step on cantilevered tables before the tension chains are securely fixed.
- When lingering on the slab formwork, measures must be taken to prevent falling, e.g. PPE.
- Clearly mark unsecured building edges!

Close infill areas in the inner area, close infill areas at unsecured building edges after the platforms have been installed.




Fig. A9.10




Fig. A9.11



### Platform installation




# Risk of falling!

- Cantilevers should not have formwork erected or be stepped on before being firmly secured with tension chains.
- When lingering on the slab formwork, measures must be taken to prevent falling, e.g. PPE.
- Clearly mark unsecured building edges!

Begin with the platform assembly in one area in which there is no risk of falling to the rear or at the side (e.g. Area II, see Ground Plan Fig. A9.01).

- 1. With the help of the Erection Aid SSH, access the recess of the platform decking and pull the platform out from its safe position. (Fig. A9.12)
- 2. Move the platform into position at an angle from above in front of the last panel onto the cantilevered main beam.
- 3. By further lowering the platform, positive assembly is carried out:
  - The slide (45.1) on the underside of the platform is secured when positioned in the platform support (2.7) on the Main Beam SLT 375. (Fig. A9.12a)
    - → The platform is locked in position and secured against tipping.
  - The slide safety device locks into the teeth of the main beam.
    - → The platform is secured against moving in the longitudinal direction of the beam.
- 4. Detach both crane hooks. Site personnel must wear personal protection equipment (PPE) to prevent falling!
  - Crane eye swivels downwards and the securing hook grips under the self-draining edges of the main beam. If necessary, press down the crane eye.
    - → The platform is additionally secured against tipping and lifting. (Fig. A9.12b)
- 5. Install other platforms in the same way with the shuttering aid.
- 6. Close infill areas < 75 cm using contractor's own resources, e.g. scaffold planks 24 x 4.5 cm.



7. Handrails for infill areas are created using handrail boards 3 x 15 cm and toe boards (use nail holes in platform guardrails) or standard couplings and scaffold tubes.



For difficult assembly situations, e.g. wind, guide the platform with 2 shuttering aids. (Fig. A9.13)




Fig. A9.13



# Striking



### Risk of falling!

When attaching the platforms to the crane lifting gear, site personnel must wear personal protection equipment (PPE) to prevent falling.

# Open edge areas

- 1. Strike the SKYDECK slab formwork in Area IV, see ground plan Fig. A9.01, in the direction of the slab edge up to the last but one bay of the cantilevered edge area.
- 2. Important: do not lower the props (1c, 35) of the cantilevered Main Beams SLT 375 (2.6), do not release the bracing!
- 3. Lower the dropheads or props (1a, 1b).
- 4. Strike the panels and main beams in the last but one standard bay (A). (Fig. A9.15). Do not strike bays B+C yet!
- 5. Mount end-to-end side protection on slabs that have been completed.
- 6. Attach 2-sling lifting gear to crane eyes of the platform decking.
- area (bays B + C), lower the dropheads or props, remove panels and

### Corner table

- 1. If this has not already been done: mount end-to-end side protection on slabs that have been completed.
- 2. Raise the external and internal plat-
- 3. Move the SKYDECK Transportation Fork under the timbers of the table.
- 4. Loosen the tension chains on the corner tables.
- 5. Retract the MULTIPROP Props MP. In areas with parapet walls, continue to retract or remove the props.
- 6. Lower the corner table. 7. Remove the infill area around the col-
- 8. Move the table horizontally in the direction of Area III.

### Components

- Drophead SFK
- 2.6 Main Beam SLT 375
- 2.7 Platform Support
- 23 Tension chain
- Base Plate RS
- MULTIPROP Prop MP
- 45 SKYDECK Platform SDK




Fig. A9.15

Instructions for Assembly and Use - Standard Configuration



# Working and safety scaffold

Use the SKYDECK Platform SDB 300 for longer slab sections.

Also for corner tables, the Platform SDB 300 can be used instead of the Platform SDB 150.

Use the Platform SDB 225 as a compensation platform.

The Platform SDB 225 has 4 slides on the underside. This means the platform can therefore cantilever to the right or the left by 75 cm if required. This is necessary to accommodate interruptions such as columns, offset walls or at an external wall. (Fig. A9.16)

The various platforms in use form a working and safety scaffold according to DIN 4420, Part 1.

With 1.30 m platform width they fulfil the safety scaffold requirements for a maximum 3.0 m falling height, which is required for the construction of supports or columns. (Fig. A9.17)

# DIN 4420 T1, Table 1:

Falling height H [m]	to	2,00	3,00
Min. spacing B [m]	min.	0,90	1,30



Do not assemble push-pull props on the platform nor store materials! (Fig. A9.17a)

Take into account the permissible load of 1.5 kN/m² (150kg/m²)!




Fig. A9.16





Fig. A9.17 Fig. A9.17a



# System with Prophead SSK

If the Prophead SSK is used in the main bay, then the Transition Head SDFK (26) is to be used when changing direction. Mount the Transition Head SDSK with the two bolts and nuts (26.1) – which are included in the delivery – on the slab props.

During assembly of the prophead ensure that group of nuts (26.1) point towards the support of the MULTIPROP Props. Otherwise, overlapping may occur between the nuts and weld seam.



With the change in direction, the main bays are turned 90° without having to assemble a new system.

As a result, T- and L-shaped ground plans are possible.

The change of direction is realized using the Main Beams SLT 150 in the outer row of the main bay.



- The Transition Head SDSK with the two bolts and nuts (26.1) – which are included in the delivery – must be mounted on the slab prop.
- The Prophead SDSK for changing direction must be used with 3 Main Beams SLT!




Fig. A10.01




Fig. A10.02

### Overview

(Fig. A10.02)

# Assembly of main bay direction

Assemble slab formwork in the direction of the main bay with slab props, Prophead SSK (6), Main Beam SLT 225 (2) and Panels SDP (3): see Section A4 Shuttering.

# Section A-A




Fig. A10.02a



# **Changing direction**

# Main bay direction


- Install slab prop with Prophead SDSK (26) with a spacing of 1.50 m and secure with tripods.
- 2. Mount Main Beam SLT 150 (2.5) instead of SLT 225. (Fig. A10.02 + A10.02a)

### Transverse bay direction

- 3. Continue assembling in the direction of the transverse bay with slab prop, Prophead SSK (6) and Main Beams SLT: see Section A4 Shuttering. (Fig. A10.02 + A10.03) Secure slab props with tripods.
- 4. Install Panels SDP 150 x 75 (3) in the direction of the transverse bay. (Fig. A10.02)
- 5. If a gap occurs with the Panel SDP between the transverse bay direction and main bay direction, this is closed using filler timber (12) and filler plates (16). (Fig. A10.04)

Fig. A10.03

**Section B-B** with filler timber



2.5

26

2.5

# Required components per change of direction bays

26	Prophead SDSK*	1x
26.1	Bolt M12 with MP Nut	2x
6	Prophead SSK	1x
2.5	Main Beam SLT 150	1x
2	Main Beam SLT 225**	1x
3	Panel SDP**	X
12	Filler Timber SPH	1x
16	Filler plate	1x

<sup>\*</sup> Transition Head SDSK

# Transverse bay direction

without filler timber

**Detail X** 

<sup>\*\*</sup> Depending on size of bay or plan



# System with Drophead SFK

If the Drophead SFK is used in the main bay, then the Transition Head SDFK (27) is to be used when changing direction. It consists of a Drophead (27.1) and Connector (27.2).

# Changing the main bay direction by 90°

With the change in direction, the main bays are turned 90° without having to assemble a new system.

As a result, T- and L-shaped ground plans are possible.



The change of direction is realized using Main Beams SLT, additional slab props with Transition Head SDFK in the outer row of the main bay as well as the Frame MRK.

# Required components per change of direction bays

1	Drophead SFK	1x
2	Main Beam SLT 225	1x
2a	Main Beam SLT 150 / 225	1x
3	Panel SDP 150 x 75	1x
3.1	Panel SDP 150 x 37.5	1x
9	Edge Beam SRT 150	1x
11	End Support SSL	1x
12	Filler Timber SPH	1x
16	Filler plate	1x
27.1	Drophead SDFK*	1x
27.2	Connector SDFK*	1x
30	Tripod	1x

<sup>\*</sup> Transition Head SDFK

### Overview

(Fig. A10.06 + A10.06a)

# Assembly of main bay direction

Assemble slab formwork in the direction of the main bay with slab props, Drophead SFK (1), Main Beam SLT 225 (2) and Panels SDP (3): see Section A4 Shuttering.




Fig. A10.06

# Change in direction in the edge bay with Main Beam SLT 375 3 3a 3.1 9/12 3 2 2.5 11

Fig. A10.06a



### **Changing direction**

# Main bay direction

- Insert the Connector (27.1) with the groove bolt into the Main Beam SLT 225 (main bay) and tighten by hand. (Fig. A10.07)
- 2. Mount the Transition Head SDFK (27.2) individually or with the slab prop in the connector. (Fig. A10.07a)
- 3. Mount the second Drophead SDFK at a distance of 1.50 m. (Fig. A10.06)



- Position one slab prop with Drophead SFK (1a) in the direction of the transverse bay. (Fig. A10.06)
- 5. Position second slab prop with Drophead SFK (1b) and secure slab props with tripods (30). (Fig. A10.06)
- Mount Main Beam SLT 150 / 225 (2a) in the Dropheads. (Fig. A10.06, A10.08, A10.08a)



Assemble additional transverse bays in the same way as the first transverse bay along the Main Beam SLT 225. (Fig. A10.06)

- Spacing (bay width) 1.50 m,
- without Frame MRK,
- see Section A4 Shuttering.

### **Install Panel SDP:**

Insert panels in the direction of the main bay.


- 1. Insert Panel SDP 150 x 75 (3a).
- 2. Insert Filler Panel SDP 150 x 37.5 (3.1).
- 3. Fix End Support SSL (11) to the Main Beam SLT in the filler area. Install Edge Beam SRT 150-2 (9) as well as Filler Timber SPH 225 (12) and filler plates (16), see Section A5 Infills. (Fig. A10.06, A10.06a, A10.08a)


# Continue assembling the transverse bays


Assemble transverse bay with slab props, Drophead SFK (1), Main Beam SLT 225 (2) and Panels SDP (3), see Section A4 Shuttering.



If a Drophead SDFK encounters the position of a Drophead SFK in the direction of the main bay, a 75 cm intermediate bay is to be installed. After this, installation continues with spacings of 1.50 m. (Fig. A10.09)








# **Section B-B** with filler timber

Fig. A10.08a





The Main Beam SLT must be positioned in the direction of the slab inclination. Align Props with Drophead SFK at right-angles to the Main Beams SLT 225.

The use with Prophead SSK is also possible. (Fig. A11.01)



When using PEP Slab Props, the Drophead SFK is diagonally bolted by means of 2 Bolts M12 x 35-8.8 and Nut M12. Tension forces and prop loads: see Table A15.01.

# Bracing with Tension Sleeve SAO and Chain 3.0 kN

# **Assembly**

- Set up first bay with tripods or Frame MRK.
- Mount Base Plate (24) on a sufficiently load-bearing surface area, e.g. using PERI Anchor Bolt 14/20x130, Item no. 124777. Take into consideration the Technical Data Sheet!
- 3. Screw on Tension Sleeve SAO (39) to Main Beam SLT.
- 4. Attach Anchor Chain (23) to Tension Sleeve SAO (39).
- 5. Secure Anchor Chain to Base Plate using bolts, and secure bolts by means of cotter pins.
- 6. Tension Anchor Chain. (Fig. A11.01)

- 23 Anchor Chain (permissible tension force = 3 kN)
- 24 Base Plate RS
- 24.1 Anchor Bolt PERI 14/20 x 130
- 39 Tension Sleeve SAO




Fig. A11.01



# **Bracing with Tension Unit SD**



Bracing angle  $\alpha$  selection: see Table A15.02

Tension forces and prop loads: see Tables A15.03 – A15.08.

### **Assembly**

- 1. Position slab prop with tripod.
- 2. Place the Tension Unit Upper Part (41.1) on the end plates of the Main Beam SLT (2.8) and attach the Main Beam to the Drophead SFK. (Fig. A11.03)
- 3. Swivel up the Main Beam with the second slab prop. Tension Unit must lie on the end plates of the Main Beam SLT.
- 4. Mount Base Plate (24) on a sufficiently load-bearing surface area, e.g. using PERI Anchor Bolt 14/20x130, Item no. 124777. Take into consideration the Technical Data Sheet!
- 5. Insert the Tie Yoke of the Tension Unit Upper Part onto the Tie Rod (41.3), secure with the Hex. Nut SW 30/50 (42), and attach to the Tension Unit Upper Part. (Fig. A11.03 + A11.04)
- 6. Fix Tension Unit Lower Part (41.2) to the Base Plate by means of bolts, and secure bolts using cotter pins. (Fig. A11.02)
- 7. Insert Tie Yoke of the Tension Unit Lower Part onto the Tie Rod, secure with Triple Wingnut DW 15 (43), and attach to the Tension Unit Lower Part. (Fig. A11.05 + A11.06)
- 8. Tension the Tension Unit using a Triple Wingnut.

- **24** Base Plate RS
- 24.1 Anchor Bolt PERI 14/20 x 130
- 41 Tension Unit SD




Fig. A11.02




Fig. A11.03





Fig. A11.06



# **A12 Striking**





# Setting times: see Tables! Keep access ways free!

Dismantling takes place from a safe and secure position, e.g. with PERI Stripping Cart ASW 465.

### Lowering

- Lower dropheads over large area. Release wedges with hammer. Pay attention to direction of wedge!
  - → Between the panel and slab underside there is a clearance of approx. 6 cm. (Fig. A12.01)



Striking takes place firstly on the transverse infills and then the longitudinal infills

- Remove props and store in pallets.
- Dismantle system supplements such as filler timbers, edge beams, end supports and combiheads, and store in pallets. (Fig. A12.02)
- Remove filler plates.



Striking is carried out by means of a safe mobile scaffold!




Fig. A12.01




Fig. A12.02



### **Panels**

Always begin in the corner where both infills meet.

- Dismantle Panel SDP in one bay after the other – begin with the middle panel.
- Lift panel and push approx. 10 cm in the direction of the compensation area. Pivot downwards and store in pallets.

(Fig. A12.03)


### Main beams

Pivot Main Beam SLT slowly downwards, remove and store in pallets.
 (Fig. A12.04)

Only drophead props (1) with Cover Strips SAL (4) remain standing. (Fig. A12.05)



- Remove props on walls and store in pallets.
- Remove filler areas around columns.



- lower drophead props, remove props and store in pallets.
- remove Cover Strips SAL (4).



With larger spans, begin in the middle with lowering and removal of the props.

# Cleaning

Clean SKYDECK components before the next use and spray once again, e.g. with PERI Bio Clean.

See introduction "Cleaning and maintenance".




Fig. A12.03




Fig. A12.04




Fig. A12.05

# **A13 Site record**



Company: Project: Component:		
This page is to be co	opied, filled out and filed in the daily construction records	
	Slab thickness	= cm
V	Clear room height	= m
Execution / Installation of the formwork	Prop length = clear room height – formwork assembly height (with Drophead: 41 cm)	= m
n of t	Max. panel span	= cm
Illatio	Selected prop	=
on / Insta	Actual prop load (according to PERI Tables)	= kN
Execution	Direction of assembly	Inner tube bottom  Outer tube bottom
	≤ zul. Stützenlast (nach PERI Tabellen)	= kN
eting	Check whether above assumptio on the construction site	ns and/or specifications apply
concr	Slab thickness	= cm
fore o	Max. panel span	= cm
te be:	Selected prop	= m
on site before concreting	Selected prop length	= m
	Direction of assembly	Inner tube bottom  Outer tube bottom
Check to be carried out on the construct	Are all props in both axes in a vertical position? ≤ 1%	yes
arried ou	Horizontal support for the formwork available in all directions?	yes
to be co	Mounted parts are obviously undamaged?	yes
Check	Required bracing has been mounted?	yes
Place	Date	Site manager in charge

(Signature)

# **A14 Horizontal loads with Slab Props PEP**



System with Drophead SFK or Prophead SSK and Main Beam SLT 225



- Horizontal loads per boundary bay are determined for an open building edge on one side!
- Bolt Drophead SFK to Slab Prop
- Increase prop loads in the braced areas by  $\Delta V = 2.60 \text{ kN}!$

	Load	Horizontal Lo	ad <sub>edge area</sub> [kN]	Load	Load case combination LFK 1: Concreting*			Load case combination LFK 2: Storm**			Storm**
Slab	according	c = 1.50 m	c = 0.75 m	Horizontal Lo	ad <sub>inner bay</sub> [kN]	Horizontal Lo	ad <sub>edge area</sub> [kN]	Horizontal Lo	ad <sub>inner bay</sub> [kN]	Horizontal Lo	ad <sub>edge area</sub> [kN]
thickness [cm]	to DIN EN 12812 [kN/m²]	from stopend formwork pressure	from stopend formwork pressure	Panel span c = 1.50 m	Panel span c = 0.75 m	Panel span c = 1.50 m	Panel span c = 0.75 m	Panel span c = 1.50 m	Panel span c = 0.75 m	Panel span c = 1.50 m	Panel span c = 0.75 m
14	5.13	0.518	0.259	0.354	0.177	1.349	0.675	0.033	0.016	1.232	0.616
16	5.62	0.650	0.325	0.388	0.194	1.516	0.758	0.033	0.016	1.232	0.616
18	6.11	0.798	0.399	0.422	0.211	1.697	0.849	0.033	0.016	1.232	0.616
20	6.60	0.960	0.480	0.455	0.228	1.893	0.947	0.033	0.016	1.232	0.616
22	7.09	1.137	0.568	0.489	0.245	2.104	1.052	0.033	0.016	1.256	0.628
24	7.58	1.328	0.664	0.523	0.262	2.329	1.165	0.033	0.016	1.279	0.639
25	7.83	1.430	0.715	0.540	0.270	2.447	1.224	0.033	0.016	1.291	0.645
26	8.07	1.535	0.767	0.557	0.278	2.569	1.285	0.033	0.016	1.302	0.651
28	8.56	1.756	0.878	0.591	0.295	2.824	1.412	0.033	0.016	1.326	0.663
30	9.05	1.991	0.996	0.624	0.312	3.094	1.547	0.033	0.016	1.349	0.675
35	10.38	2.701	1.351	0.716	0.358	3.895	1.948	0.033	0.016	1.408	0.704
40	11.73	3.528	1.764	0.809	0.405	4.815	2.408	0.033	0.016	1.466	0.733
43	12.54	4.077	2.039	0.865	0.433	5.425	2.712	0.033	0.016	1.501	0.751
45	13.08		2.233		0.451		2.926		0.016		0.762
50	14.43		2.756		0.498		3.500		0.016		0.792
55	15.77		3.335		0.544		4.129		0.016		0.821
60	17.12		3.969		0.591		4.814		0.016		0.850
65	18.47		4.658		0.637		5.553		0.016		0.879
70	19.82		5.402		0.684		6.347		0.016		0.909
75	21.08		6.152		0.727		7.145		0.016		0.938
80	22.30		6.930		0.769		7.968		0.016		0.967
85	23.53		7.754		0.812		8.838		0.016		0.996
90	24.75		8.623		0.854		9.753		0.016		1.026

Table A14.01

Load case combination LFK 1: working operations + tilting position + stopend formwork pressure + working wind speed.

<sup>\*\*</sup>Load case combination LFK 2: tilting position (without concrete load) + maximum wind speed [before concreting].



# Maximum permissible slab inclination with Tension Sleeve SAO and Chain 3.0 kN

# **Considered horizontal loads**

Horizontal load from working operations = 1% of the vertical load (DIN EN 12812; 8.2.2.2) = 1% of the vertical load (DIN EN 12812; 9.3.4.2)

Angle  $\alpha$  between Chain and SLT 225 = 60°

Max. tension force of Tension Sleeve SAO and Anchor Chain = 3.0 kN

		Panel	span c = 1.50 m	[cm]	Panel span c = 0.75 m [cm]				
			max. slab	inclination		max. slab	inclination		
Slab thickness	Load DIN EN 12812	increased prop load	Incline	Angle	increased prop load	Incline	Angle		
[cm]	[kN/m²]	[kN]	[%]	[°]	[kN]	[%]	[°]		
14	5.13	20.3	5.4	3.1	11.4	11.1	6.3		
16	5.62	22.0	4.8	2.8	12.3	10.2	5.8		
18	6.11	23.7	4.3	2.5	13.1	9.4	5.4		
20	6.60	25.4	3.9	2.2	14.0	8.7	5.0		
22	7.09	27.1	3.5	2.0	14.8	8.1	4.6		
24	7.58	28.7	3.2	1.8	15.7	7.6	4.3		
25	7.83	29.6	3.1	1.8	16.1	7.3	4.2		
26	8.07	30.4	2.9	1.7	16.5	7.1	4.1		
28	8.56	32.1	2.7	1.5	17.4	6.6	3.8		
30	9.05	33.8	2.4	1.4	18.2	6.2	3.6		
35	10.38	38.4	1.9	1.1	20.5	5.3	3.0		
40	11.73	43.1	1.5	0.8	22.8	4.6	2.6		
43	12.54	45.9	1.3	0.7	24.2	4.2	2.4		
45	13.08				25.2	4.0	2.3		
50	14.43				27.5	3.5	2.0		
55	15.77				29.8	3.0	1.7		
60	17.12				32.1	2.7	1.5		
65	18.47				34.5	2.4	1.3		
70	19.82				36.8	2.1	1.2		
75	21.08				39.0	1.8	1.1		
80	22.30				41.1	1.7	0.9		
85	23.53				43.2	1.5	0.8		
90	24.75				45.3	1.3	0.8		

Table A15.01

# SKYDECK Tension Unit SD – bracing angle $\alpha$ selection

Angle α Tension Unit	possible clea with SSK a	•	possible clear room height with SFK and SLT 225		
SD	min h <sub>minimum clearance</sub>	max h <sub>minimum clearance</sub>	min h <sub>minimum clearance</sub>	max h <sub>minimum clearance</sub>	
30 °	1.72 m	2.01 m	1.73 m	2.02 m	
35 °	2.02 m	2.34 m	2.04 m	2.36 m	
40 °	2.37 m	2.71 m	2.39 m	2.73 m	
45 °	2.77 m	3.12 m	2.80 m	3.15 m	
50 °	3.25 m	3.60 m	3.28 m	3.63 m	
55 °	3.84 m	4.16 m	3.88 m	4.20 m	
60 °	4.60 m	4.87 m	4.65 m	4.91 m	



# Tension force of Tension Unit SD and system prop loads with Drophead SFK



- The Drophead SFK is bolted to the PEP Slab Props.
- The PEP Props are to be assembled with the inner tube bottom.

### **Considered horizontal loads**

Horizontal load from working operations = 1% of the vertical load (DIN EN 12812; 8.2.2.2) Horizontal load from the tilting position = 1% of the vertical load (DIN EN 12812; 9.3.4.2)

### Inclination of slab 1%

	max. inclination			5 connected bays		4 connected bays		3 conne	cted bays
Angle α			Standard	Tension force	Braced prop	Tension force	Braced prop	Tension force	Braced prop
	ncline [%]	Angle β	prop Full load	Tension Unit SD	full load V <sub>ges</sub>	Tension Unit	full load	Tension Unit	full load V <sub>ges</sub>

# Slab thickness 20 cm, $q = 6.60 \text{ kN/m}^2$

30 °	1.0%	0.6 °	22.8 kN	3.9 kN	24.7 kN	3.2 kN	24.3 kN	2.4 kN	24.0 kN
35 °	1.0%	0.6 °	22.8 kN	4.2 kN	25.2 kN	3.3 kN	24.7 kN	2.5 kN	24.2 kN
40 °	1.0%	0.6 °	22.8 kN	4.5 kN	25.6 kN	3.6 kN	25.1 kN	2.7 kN	24.5 kN
45 °	1.0%	0.6 °	22.8 kN	4.8 kN	26.2 kN	3.9 kN	25.5 kN	2.9 kN	24.8 kN
50 °	1.0%	0.6 °	22.8 kN	5.3 kN	26.8 kN	4.3 kN	26.0 kN	3.2 kN	25.2 kN
55 °	1.0%	0.6 °	22.8 kN	6.0 kN	27.6 kN	4.8 kN	26.7 kN	3.6 kN	25.7 kN
60 °	1.0%	0.6 °	22.8 kN	6.8 kN	28.7 kN	5.5 kN	27.5 kN	4.1 kN	26.3 kN

# Slab thickness 24 cm, $q = 7.58 \text{ kN/m}^2$

30 °	1.0%	0.6 °	26.2 kN	4.5 kN	28.4 kN	3.6 kN	28.0 kN	2.7 kN	27.5 kN
35 °	1.0%	0.6 °	26.2 kN	4.8 kN	28.9 kN	3.8 kN	28.3 kN	2.9 kN	27.8 kN
40 °	1.0%	0.6 °	26.2 kN	5.1 kN	29.4 kN	4.1 kN	28.8 kN	3.1 kN	28.1 kN
45 °	1.0%	0.6 °	26.2 kN	5.5 kN	30.1 kN	4.4 kN	29.3 kN	3.3 kN	28.5 kN
50 °	1.0%	0.6 °	26.2 kN	6.1 kN	30.8 kN	4.9 kN	29.9 kN	3.7 kN	29.0 kN
55 °	1.0%	0.6 °	26.2 kN	6.8 kN	31.8 kN	5.5 kN	30.6 kN	4.1 kN	29.5 kN
60 °	1.0%	0.6 °	26.2 kN	7.8 kN	32.9 kN	6.3 kN	31.6 kN	4.7 kN	30.2 kN

# Slab thickness 25 cm, $q = 7.83 \text{ kN/m}^2$

30 °	1.0%	0.6 °	27.0 kN	4.7 kN	29.4 kN	3.7 kN	28.9 kN	2.8 kN	28.4 kN
35 °	1.0%	0.6 °	27.0 kN	4.9 kN	29.9 kN	4.0 kN	29.3 kN	3.0 kN	28.7 kN
40 °	1.0%	0.6 °	27.0 kN	5.3 kN	30.4 kN	4.2 kN	29.7 kN	3.2 kN	29.1 kN
45 °	1.0%	0.6 °	27.0 kN	5.7 kN	31.1 kN	4.6 kN	30.3 kN	3.4 kN	29.4 kN
50 °	1.0%	0.6 °	27.0 kN	6.3 kN	31.8 kN	5.0 kN	30.9 kN	3.8 kN	29.9 kN
55 °	1.0%	0.6 °	27.0 kN	7.1 kN	32.8 kN	5.7 kN	31.6 kN	4.2 kN	30.5 kN
60 °	1.0%	0.6 °	27.0 kN	8.1 kN	34.0 kN	6.5 kN	32.6 kN	4.9 kN	31.2 kN

# Slab thickness 30 cm, $q = 9.05 \text{ kN/m}^2$

30 °	1.0%	0.6 °	31.2 kN	5.4 kN	33.9 kN	4.3 kN	33.4 kN	3.2 kN	32.8 kN
35 °	1.0%	0.6 °	31.2 kN	5.7 kN	34.5 kN	4.6 kN	33.8 kN	3.4 kN	33.2 kN
40 °	1.0%	0.6 °	31.2 kN	6.1 kN	35.2 kN	4.9 kN	34.4 kN	3.7 kN	33.6 kN
45 °	1.0%	0.6 °	31.2 kN	6.6 kN	35.9 kN	5.3 kN	35.0 kN	4.0 kN	34.0 kN
50 °	1.0%	0.6 °	31.2 kN	7.3 kN	36.8 kN	5.8 kN	35.7 kN	4.4 kN	34.6 kN
55 °	1.0%	0.6 °	31.2 kN	8.2 kN	37.9 kN	6.5 kN	36.6 kN	4.9 kN	35.2 kN
60 °	1.0%	0.6 °	31.2 kN	9.4 kN	39.3 kN	7.5 kN	37.7 kN	5.6 kN	36.1 kN



# System with Drophead SFK Tension force of Tension Unit SD and prop loads



- The Drophead SFK is bolted to the PEP Slab Props.
- The PEP Props are to be assembled with the inner tube bottom.

### **Considered horizontal loads**

Horizontal load from working operations = 1% of the vertical load (DIN EN 12812; 8.2.2.2) Horizontal load from the tilting position = 1% of the vertical load (DIN EN 12812; 9.3.4.2)

### Inclination of slab 5%

	max. in	clination		5 connected bays		4 connected bays		3 connected bays	
				Tension		Tension		Tension	
Angle α			Standard	force	Braced prop	force	Braced prop	force	Braced prop
Tension Unit	Incline	Angle β	prop	Tension	Full load	Tension Unit	Full load	Tension Unit	Full load
SD	[%]	[°]	Full load	Unit SD	V <sub>ges</sub>	SD	V <sub>ges</sub>	SD	$V_{ges}$

# Slab thickness 20 cm, $q = 6.60 \text{ kN/m}^2$

30 °	5.0%	2.9 °	22.8 kN	9.2 kN	27.4 kN	7.4 kN	26.5 kN	5.5 kN	25.5 kN
35 °	5.0%	2.9 °	22.8 kN	9.7 kN	28.4 kN	7.8 kN	27.2 kN	5.8 kN	26.1 kN
40 °	5.0%	2.9 °	22.8 kN	10.4 kN	29.5 kN	8.3 kN	28.1 kN	6.2 kN	26.8 kN
45 °	5.0%	2.9 °	22.8 kN	11.3 kN	30.7 kN	9.0 kN	29.1 kN	6.8 kN	27.6 kN
50 °	5.0%	2.9 °	22.8 kN	-	-	9.9 kN	30.4 kN	7.4 kN	28.5 kN
55 °	5.0%	2.9 °	22.8 kN	-	_	11.1 kN	31.9 kN	8.3 kN	29.6 kN
60 °	5.0%	2.9 °	22.8 kN	-	_	-	_	9.6 kN	31.1 kN

# Slab thickness 24 cm, $q = 7.58 \text{ kN/m}^2$

30 °	5.0%	2.9 °	26.2 kN	10.6 kN	31.4 kN	8.5 kN	30.4 kN	6.3 kN	29.3 kN
35 °	5.0%	2.9 °	26.2 kN	11.2 kN	32.6 kN	8.9 kN	31.3 kN	6.7 kN	30.0 kN
40 °	5.0%	2.9 °	26.2 kN	11.9 kN	33.8 kN	9.6 kN	32.3 kN	7.2 kN	30.8 kN
45 °	5.0%	2.9 °	26.2 kN	12.9 kN	35.3 kN	10.4 kN	33.5 kN	7.8 kN	31.6 kN
50 °	5.0%	2.9 °	26.2 kN	-	-	11.4 kN	34.9 kN	8.5 kN	32.7 kN
55 °	5.0%	2.9 °	26.2 kN	-	_	12.8 kN	36.6 kN	9.6 kN	34.0 kN
60 °	5.0%	2.9 °	26.2 kN	-	_	-	_	11.0 kN	35.7 kN

# Slab thickness 25 cm, $q = 7.83 \text{ kN/m}^2$

30 °	5.0%	2.9 °	27.0 kN	10.9 kN	32.5 kN	8.7 kN	31.4 kN	6.6 kN	30.3 kN
35 °	5.0%	2.9 °	27.0 kN	11.5 kN	33.6 kN	9.2 kN	32.3 kN	6.9 kN	31.0 kN
40 °	5.0%	2.9 °	27.0 kN	12.3 kN	34.9 kN	9.9 kN	33.4 kN	7.4 kN	31.8 kN
45 °	5.0%	2.9 °	27.0 kN	13.4 kN	36.5 kN	10.7 kN	34.6 kN	8.0 kN	32.7 kN
50 °	5.0%	2.9 °	27.0 kN	-	-	11.8 kN	36.0 kN	8.8 kN	33.8 kN
55 °	5.0%	2.9 °	27.0 kN	-	-	13.2 kN	37.8 kN	9.9 kN	35.1 kN
60 °	5.0%	2.9 °	27.0 kN	-	-	-	-	11.3 kN	36.8 kN

# Slab thickness 30 cm, $q = 9.05 \text{ kN/m}^2$

30 °	5.0%	2.9 °	31.2 kN	12.6 kN	37.5 kN	10.1 kN	36.3 kN	7.6 kN	35.0 kN
35 °	5.0%	2.9 °	31.2 kN	13.3 kN	38.9 kN	10.7 kN	37.3 kN	8.0 kN	35.8 kN
40 °	5.0%	2.9 °	31.2 kN	14.3 kN	40.4 kN	11.4 kN	38.6 kN	8.6 kN	36.7 kN
45 °	5.0%	2.9 °	31.2 kN	15.5 kN	42.2 kN	12.4 kN	40.0 kN	9.3 kN	37.8 kN
50 °	5.0%	2.9 °	31.2 kN	_	-	13.6 kN	41.6 kN	10.2 kN	39.0 kN
55 °	5.0%	2.9 °	31.2 kN	-	_	15.2 kN	43.7 kN	11.4 kN	40.6 kN
60 °	5.0%	2.9 °	31.2 kN	-	-	-	_	13.1 kN	42.6 kN



# System with Drophead SFK Tension force of Tension Unit SD and prop loads



- The Drophead SFK is bolted to the PEP Slab Props.
- The PEP Props are to be assembled with the inner tube bottom.

### **Considered horizontal loads**

Horizontal load from working operations = 1% of the vertical load (DIN EN 12812; 8.2.2.2) Horizontal load from the tilting position = 1% of the vertical load (DIN EN 12812; 9.3.4.2)

### Inclination of slab 9%

	max. in	clination		5 connected bays		4 connected bays		3 connected bays	
				Tension		Tension		Tension	
Angle			Standard	force	Braced prop	force	Braced prop	force	Braced prop
Tension Unit	Incline	Angle	prop	Tension	Full load	Tension Unit	Full load	Tension Unit	Full load
SD	[%]	[°]	Full load	Unit SD	V <sub>ges</sub>	SD	V <sub>ges</sub>	SD	$V_{ges}$

# Slab thickness 20 cm, $q = 6.60 \text{ kN/m}^2$

				1		1			
30 °	9.0%	5.1 °	22.8 kN	14.5 kN	30.0 kN	11.6 kN	28.6 kN	8.7 kN	27.1 kN
35 °	9.0%	5.1 °	22.8 kN	15.3 kN	31.5 kN	12.2 kN	29.8 kN	9.2 kN	28.0 kN
40 °	9.0%	5.1 °	22.8 kN	-	-	13.1 kN	31.2 kN	9.8 kN	29.1 kN
45 °	9.0%	5.1 °	22.8 kN	-	-	-	_	10.6 kN	30.3 kN
50 °	9.0%	5.1 °	22.8 kN	-	-	-	_	11.7 kN	31.7 kN
55 °	9.0%	5.1 °	22.8 kN	_	-	-	_	_	-
60 °	9.0%	5.1 °	22.8 kN	-	-	-	-	-	-

# Slab thickness 24 cm, $q = 7.58 \text{ kN/m}^2$

30 °	9,0%	5,1 °	26,2 kN	16,6 kN	34,5 kN	13,3 kN	32,8 kN	10,0 kN	31,1 kN
35 °	9,0%	5,1 °	26,2 kN	17,6 kN	36,2 kN	14,0 kN	34,2 kN	10,5 kN	32,2 kN
40 °	9,0%	5,1 °	26,2 kN	-	-	15,0 kN	35,8 kN	11,3 kN	33,4 kN
45 °	9,0%	5,1 °	26,2 kN	-	-	_	-	12,2 kN	34,8 kN
50 °	9,0%	5,1 °	26,2 kN	-	-	-	-	13,4 kN	36,4 kN
55 °	9,0%	5,1 °	26,2 kN	-	-	-	-	-	-
60 °	9,0%	5,1 °	26,2 kN	-	_	_	_	ı	_

# Slab thickness 25 cm, $q = 7.83 \text{ kN/m}^2$

30 °	9.0%	5.1 °	27.0 kN	17.2 kN	35.6 kN	13.7 kN	33.9 kN	10.3 kN	32.2 kN
35 °	9.0%	5.1 °	27.0 kN	18.1 kN	37.4 kN	14.5 kN	35.3 kN	10.9 kN	33.3 kN
40 °	9.0%	5.1 °	27.0 kN	-	-	15.5 kN	37.0 kN	11.6 kN	34.5 kN
45 °	9.0%	5.1 °	27.0 kN	-	_	-	-	12.6 kN	35.9 kN
50 °	9.0%	5.1 °	27.0 kN	-	-	-	-	13.9 kN	37.6 kN
55 °	9.0%	5.1 °	27.0 kN	-	-	-	-	-	-
60 °	9.0%	5.1 °	27.0 kN	-	_	-	-	-	-

# Slab thickness 30 cm, $q = 9.05 \text{ kN/m}^2$

				T		I		T	
30 °	9.0%	5.1 °	31.2 kN	19.8 kN	41.1 kN	15.9 kN	39.2 kN	11.9 kN	37.2 kN
35 °	9.0%	5.1 °	31.2 kN	21.0 kN	43.2 kN	16.8 kN	40.8 kN	12.6 kN	38.4 kN
40 °	9.0%	5.1 °	31.2 kN	-	_	17.9 kN	42.7 kN	13.5 kN	39.9 kN
45 °	9.0%	5.1 °	31.2 kN	-	_	-	_	14.6 kN	41.5 kN
50 °	9.0%	5.1 °	31.2 kN	-	_	-	_	16.0 kN	43.5 kN
55 °	9.0%	5.1 °	31.2 kN	-	_	-	-	-	_
60 °	9.0%	5.1 °	31.2 kN	_	_	-	-	-	-



# System with Prophead SSK Tension force of Tension Unit SD and prop loads

# **Considered horizontal loads**

Horizontal load from working operations = 1% of the vertical load (DIN EN 12812; 8.2.2.2)

Horizontal load from the tilting position = 1% of the vertical load (DIN EN 12812; 9.3.4.2)

## Inclination of slab 1%

	max. inclination			5 connected bays		4 connected bays		3 connected bays	
				Tension		Tension		Tension	
Angle α			Standard	force	Braced prop	force	Braced prop	force	Braced prop
Tension Unit	Incline	Angle β	prop	Tension	Full load	Tension Unit	Full load	Tension Unit	Full load
SD	[%]	[°]	Full load	Unit SD	V <sub>ges</sub>	SD	V <sub>ges</sub>	SD	$V_{ges}$

# Slab thickness 20 cm, q = 6.60 kN/m<sup>2</sup>

30 °	1.0%	0.6 °	22.3 kN	3.9 kN	24.2 kN	3.1 kN	23.8 kN	2.3 kN	23.4 kN
35 °	1.0%	0.6 °	22.3 kN	4.1 kN	24.6 kN	3.3 kN	24.1 kN	2.4 kN	23.7 kN
40 °	1.0%	0.6 °	22.3 kN	4.4 kN	25.1 kN	3.5 kN	24.5 kN	2.6 kN	24.0 kN
45 °	1.0%	0.6 °	22.3 kN	4.7 kN	25.6 kN	3.8 kN	24.9 kN	2.8 kN	24.3 kN
50 °	1.0%	0.6 °	22.3 kN	5.2 kN	26.3 kN	4.2 kN	25.5 kN	3.1 kN	24.7 kN
55 °	1.0%	0.6 °	22.3 kN	5.8 kN	27.0 kN	4.7 kN	26.1 kN	3.5 kN	25.1 kN
60 °	1.0%	0.6 °	22.3 kN	6.7 kN	28.1 kN	5.3 kN	26.9 kN	4.0 kN	25.7 kN

# Slab thickness 24 cm, q = 7.58 kN/m<sup>2</sup>

30 °	1.0%	0.6 °	25.6 kN	4.4 kN	27.8 kN	3.5 kN	27.4 kN	2.7 kN	26.9 kN
35 °	1.0%	0.6 °	25.6 kN	4.7 kN	28.3 kN	3.7 kN	27.7 kN	2.8 kN	27.2 kN
40 °	1.0%	0.6 °	25.6 kN	5.0 kN	28.8 kN	4.0 kN	28.2 kN	3.0 kN	27.5 kN
45 °	1.0%	0.6 °	25.6 kN	5.4 kN	29.4 kN	4.3 kN	28.7 kN	3.3 kN	27.9 kN
50 °	1.0%	0.6 °	25.6 kN	6.0 kN	30.2 kN	4.8 kN	29.2 kN	3.6 kN	28.3 kN
55 °	1.0%	0.6 °	25.6 kN	6.7 kN	31.1 kN	5.4 kN	30.0 kN	4.0 kN	28.9 kN
60 °	1.0%	0.6 °	25.6 kN	7.7 kN	32.2 kN	6.1 kN	30.9 kN	4.6 kN	29.6 kN

# Slab thickness 25 cm, $q = 7.83 \text{ kN/m}^2$

30 °	1.0%	0.6 °	26.4 kN	4.6 kN	28.7 kN	3.7 kN	28.3 kN	2.7 kN	27.8 kN
35 °	1.0%	0.6 °	26.4 kN	4.8 kN	29.2 kN	3.9 kN	28.6 kN	2.9 kN	28.1 kN
40 °	1.0%	0.6 °	26.4 kN	5.2 kN	29.8 kN	4.1 kN	29.1 kN	3.1 kN	28.4 kN
45 °	1.0%	0.6 °	26.4 kN	5.6 kN	30.4 kN	4.5 kN	29.6 kN	3.4 kN	28.8 kN
50 °	1.0%	0.6 °	26.4 kN	6.2 kN	31.2 kN	4.9 kN	30.2 kN	3.7 kN	29.3 kN
55 °	1.0%	0.6 °	26.4 kN	6.9 kN	32.1 kN	5.5 kN	31.0 kN	4.1 kN	29.8 kN
60 °	1.0%	0.6 °	26.4 kN	7.9 kN	33.3 kN	6.3 kN	31.9 kN	4.8 kN	30.5 kN

# Slab thickness 30 cm, $q = 9.05 \text{ kN/m}^2$

30 °	1.0%	0.6 °	30.5 kN	5.3 kN	33.2 kN	4.2 kN	32.7 kN	3.2 kN	32.1 kN
35 °	1.0%	0.6 °	30.5 kN	5.6 kN	33.8 kN	4.5 kN	33.1 kN	3.4 kN	32.5 kN
40 °	1.0%	0.6 °	30.5 kN	6.0 kN	34.4 kN	4.8 kN	33.6 kN	3.6 kN	32.9 kN
45 °	1.0%	0.6 °	30.5 kN	6.5 kN	35.1 kN	5.2 kN	34.2 kN	3.9 kN	33.3 kN
50 °	1.0%	0.6 °	30.5 kN	7.1 kN	36.0 kN	5.7 kN	34.9 kN	4.3 kN	33.8 kN
55 °	1.0%	0.6 °	30.5 kN	8.0 kN	37.1 kN	6.4 kN	35.8 kN	4.8 kN	34.5 kN
60 °	1.0%	0.6 °	30.5 kN	9.2 kN	38.5 kN	7.3 kN	36.9 kN	5.5 kN	35.3 kN

## A15 Inclined slabs



## System with Prophead SSK Tension force of Tension Unit SD and prop loads

### **Considered horizontal loads**

Horizontal load from working operations = 1% of the vertical load (DIN EN 12812; 8.2.2.2) Horizontal load from the tilting position = 1% of the vertical load (DIN EN 12812; 9.3.4.2)

### Inclination of slab 5%

		max. in	clination		5 conne	cted bays	4 conne	cted bays	3 conne	cted bays
					Tension		Tension		Tension	
	Angle $\alpha$			Standard	force	Braced prop	force	Braced prop	force	Braced prop
T	ension Unit	Incline	Angle β prop		Tension	Full load	Tension Unit	Full load	Tension Unit	Full load
	SD	[%]	[°]	Full load	Unit SD	V <sub>ges</sub>	SD	$V_{ges}$	SD	$V_{ges}$

### Slab thickness 20 cm, $q = 6.60 \text{ kN/m}^2$

30 °	5.0%	2.9 °	22.3 kN	9.0 kN	26.8 kN	7.2 kN	25.9 kN	5.4 kN	25.0 kN
35 °	5.0%	2.9 °	22.3 kN	9.5 kN	27.7 kN	7.6 kN	26.6 kN	5.7 kN	25.6 kN
40 °	5.0%	2.9 °	22.3 kN	10.2 kN	28.8 kN	8.1 kN	27.5 kN	6.1 kN	26.2 kN
45 °	5.0%	2.9 °	22.3 kN	11.0 kN	30.1 kN	8.8 kN	28.5 kN	6.6 kN	27.0 kN
50 °	5.0%	2.9 °	22.3 kN	12.1 kN	31.6 kN	9.7 kN	29.7 kN	7.3 kN	27.8 kN
55 °	5.0%	2.9 °	22.3 kN	13.6 kN	33.4 kN	10.9 kN	31.2 kN	8.2 kN	29.0 kN
60 °	5.0%	2.9 °	22.3 kN	15.6 kN	35.8 kN	12.5 kN	33.1 kN	9.4 kN	30.4 kN

### Slab thickness 24 cm, $q = 7.58 \text{ kN/m}^2$

30 °	5.0%	2.9 °	25.6 kN	10.3 kN	30.8 kN	8.3 kN	29.7 kN	6.2 kN	28.7 kN
35 °	5.0%	2.9 °	25.6 kN	10.9 kN	31.9 kN	8.7 kN	30.6 kN	6.6 kN	29.3 kN
40 °	5.0%	2.9 °	25.6 kN	11.7 kN	33.1 kN	9.4 kN	31.6 kN	7.0 kN	30.1 kN
45 °	5.0%	2.9 °	25.6 kN	12.7 kN	34.5 kN	10.1 kN	32.7 kN	7.6 kN	31.0 kN
50 °	5.0%	2.9 °	25.6 kN	13.9 kN	36.3 kN	11.1 kN	34.1 kN	8.4 kN	32.0 kN
55 °	5.0%	2.9 °	25.6 kN	15.6 kN	38.4 kN	12.5 kN	35.8 kN	9.4 kN	33.3 kN
60 °	5.0%	2.9 °	25.6 kN	17.9 kN	41.1 kN	14.3 kN	38.0 kN	10.7 kN	34.9 kN

### Slab thickness 25 cm, $q = 7.83 \text{ kN/m}^2$

30 °	5.0%	2.9 °	26.4 kN	10.7 kN	31.8 kN	8.5 kN	30.7 kN	6.4 kN	29.6 kN
35 °	5.0%	2.9 °	26.4 kN	11.3 kN	32.9 kN	9.0 kN	31.6 kN	6.8 kN	30.3 kN
40 °	5.0%	2.9 °	26.4 kN	12.1 kN	34.2 kN	9.7 kN	32.6 kN	7.2 kN	31.1 kN
45 °	5.0%	2.9 °	26.4 kN	13.1 kN	35.7 kN	10.5 kN	33.8 kN	7.8 kN	32.0 kN
50 °	5.0%	2.9 °	26.4 kN	14.4 kN	37.4 kN	11.5 kN	35.2 kN	8.6 kN	33.0 kN
55 °	5.0%	2.9 °	26.4 kN	16.1 kN	39.6 kN	12.9 kN	37.0 kN	9.7 kN	34.4 kN
60 °	5.0%	2.9 °	26.4 kN	18.5 kN	42.4 kN	14.8 kN	39.2 kN	11.1 kN	36.0 kN

### Slab thickness 30 cm, $q = 9.05 \text{ kN/m}^2$

30 °	5.0%	2.9 °	30.5 kN	12.3 kN	36.7 kN	9.9 kN	35.5 kN	7.4 kN	34.2 kN
35 °	5.0%	2.9 °	30.5 kN	13.1 kN	38.0 kN	10.4 kN	36.5 kN	7.8 kN	35.0 kN
40 °	5.0%	2.9 °	30.5 kN	14.0 kN	39.5 kN	11.2 kN	37.7 kN	8.4 kN	35.9 kN
45 °	5.0%	2.9 °	30.5 kN	15.1 kN	41.2 kN	12.1 kN	39.1 kN	9.1 kN	37.0 kN
50 °	5.0%	2.9 °	30.5 kN	16.6 kN	43.3 kN	13.3 kN	40.7 kN	10.0 kN	38.2 kN
55 °	5.0%	2.9 °	30.5 kN	18.6 kN	45.8 kN	14.9 kN	42.8 kN	11.2 kN	39.7 kN
60 °	5.0%	2.9 °	30.5 kN	21.4 kN	49.1 kN	17.1 kN	45.4 kN	12.8 kN	41.7 kN

Table A15.07

## A15 Inclined slabs



## System with Prophead SSK Tension force of Tension Unit SD and prop loads

### **Considered horizontal loads**

Horizontal load from working operations = 1% of the vertical load (DIN EN 12812; 8.2.2.2) = 1% of the vertical load (DIN EN 12812; 9.3.4.2)

### Inclination of slab 9%

	max. in	clination		5 conne	cted bays	4 conne	cted bays	3 conne	cted bays
				Tension		Tension		Tension	
Angle α			Standard	force	Braced prop	force	Braced prop	force	Braced prop
Tension Unit	Incline	Angle β	prop	Tension	Full load	Tension Unit	Full load	Tension Unit	Full load
SD	[%]	[°]	Full load	Unit SD	V <sub>ges</sub>	SD	V <sub>ges</sub>	SD	$V_{ges}$

### Slab thickness 20 cm. q = 6.60 kN/m<sup>2</sup>

30 °	9.0%	5.1 °	22.3 kN	14.1 kN	29.3 kN	11.3 kN	27.9 kN	8.5 kN	26.5 kN
35 °	9.0%	5.1 °	22.3 kN	15.0 kN	30.9 kN	12.0 kN	29.1 kN	9.0 kN	27.4 kN
40 °	9.0%	5.1 °	22.3 kN	16.0 kN	32.6 kN	12.8 kN	30.5 kN	9.6 kN	28.4 kN
45 °	9.0%	5.1 °	22.3 kN	17.3 kN	34.5 kN	13.9 kN	32.1 kN	10.4 kN	29.6 kN
50 °	9.0%	5.1 °	22.3 kN	19.1 kN	36.9 kN	15.2 kN	34.0 kN	11.4 kN	31.0 kN
55 °	9.0%	5.1 °	22.3 kN	21.4 kN	39.8 kN	17.1 kN	36.3 kN	12.8 kN	32.8 kN
60 °	9.0%	5.1 °	22.3 kN	-	-	19.6 kN	39.3 kN	14.7 kN	35.0 kN

### Slab thickness 24 cm. $q = 7.58 \text{ kN/m}^2$

30 °	9.0%	5.1 °	25.6 kN	16.2 kN	33.7 kN	13.0 kN	32.1 kN	9.7 kN	30.5 kN
35 °	9.0%	5.1 °	25.6 kN	17.2 kN	35.4 kN	13.7 kN	33.5 kN	10.3 kN	31.5 kN
40 °	9.0%	5.1 °	25.6 kN	18.4 kN	37.4 kN	14.7 kN	35.0 kN	11.0 kN	32.7 kN
45 °	9.0%	5.1 °	25.6 kN	19.9 kN	39.7 kN	15.9 kN	36.8 kN	11.9 kN	34.0 kN
50 °	9.0%	5.1 °	25.6 kN	21.9 kN	42.4 kN	17.5 kN	39.0 kN	13.1 kN	35.6 kN
55 °	9.0%	5.1 °	25.6 kN	-	-	19.6 kN	41.7 kN	14.7 kN	37.6 kN
60 °	9.0%	5.1 °	25.6 kN	-	-	22.5 kN	45.1 kN	16.9 kN	40.2 kN

### Slab thickness 25 cm. q = 7.83 kN/m<sup>2</sup>

30 °	9.0%	5.1 °	26.4 kN	16.8 kN	34.8 kN	13.4 kN	33.1 kN	10.1 kN	31.5 kN
35 °	9.0%	5.1 °	26.4 kN	17.7 kN	36.6 kN	14.2 kN	34.6 kN	10.6 kN	32.5 kN
40 °	9.0%	5.1 °	26.4 kN	19.0 kN	38.6 kN	15.2 kN	36.2 kN	11.4 kN	33.7 kN
45 °	9.0%	5.1 °	26.4 kN	20.6 kN	41.0 kN	16.4 kN	38.1 kN	12.3 kN	35.1 kN
50 °	9.0%	5.1 °	26.4 kN	22.6 kN	43.7 kN	18.1 kN	40.3 kN	13.6 kN	36.8 kN
55 °	9.0%	5.1 °	26.4 kN	-	-	20.3 kN	43.0 kN	15.2 kN	38.9 kN
60 °	9.0%	5.1 °	26.4 kN	-	_	23.3 kN	46.6 kN	17.4 kN	41.5 kN

### Slab thickness 30 cm. q = 9.05 kN/m<sup>2</sup>

30 °	9.0%	5.1 °	30.5 kN	19.4 kN	40.2 kN	15.5 kN	38.3 kN	11.6 kN	36.4 kN
35 °	9.0%	5.1 °	30.5 kN	20.5 kN	42.3 kN	16.4 kN	40.0 kN	12.3 kN	37.6 kN
40 °	9.0%	5.1 °	30.5 kN	21.9 kN	44.6 kN	17.5 kN	41.8 kN	13.2 kN	39.0 kN
45 °	9.0%	5.1 °	30.5 kN	23.8 kN	47.3 kN	19.0 kN	44.0 kN	14.3 kN	40.6 kN
50 °	9.0%	5.1 °	30.5 kN	_	_	20.9 kN	46.6 kN	15.7 kN	42.6 kN
55 °	9.0%	5.1 °	30.5 kN	-	_	23.4 kN	49.7 kN	17.6 kN	44.9 kN
60 °	9.0%	5.1 °	30.5 kN	_	_	_	_	20.2 kN	48.0 kN

Table A15.08

## A16 SKYDECK





				M	ain Bear	n SLT 2	25		,			М	ain Bear	n SLT 1	50		
		Pa	anel spar	n c 1.50	m	Pa	anel spar	c 0.75	m	Р	anel spar	n c 1.50	m	Pa	anel span	c 0.75	m
less d [r	N/m²]		load N]	Defle line	ection e**		load N]	Defle line			load :N]		ection e**		load N]	Defle line	ection e**
Slab thickness d [m]	Load q* [kN/m²]		with Centre Support SSK		with Centre Support SSK		with Centre Support SSK		with Centre Support SSK		with Centre Support SSK		with Centre Support SSK		with Centre Support SSK		with Centre Support SSK
0.14	5.13	17.7		7		8.8		7		11.9		7					
0.16	5.62	19.4		7		9.7		7		13.1		7					
0.18	6.11	21.1		7		10.5		7		14.2		7					
0.20	6.60	22.8		7		11.4		7		15.3		7					
0.22	7.09	24.5		7		12.2		7		16.5		7					
0.24	7.58	26.2		7		13.1		7		17.6		7					
0.25	7.83	27.0		7		13.5		7		18.2		7					
0.26	8.07	27.8		7		13.9		7		18.8		7					
0.28	8.56	29.5	16.2	7	7	14.8		7		19.9		7					
0.30	9.05	31.2	17.2	7	7	15.6		7		21.0		7					
0.35	10.38	35.8	19.7	7	7	17.9		7		24.1		7					
0.40	11.73	40.5	22.3	6	7	20.2		7		27.3		7					
0.43	12.54	43.3	23.6	6	6	21.4		7		29.2		6					
0.45	13.08		24.8		6	22.6		7		30.4		6					
0.50	14.43		27.4		6	24.9		7		33.5		6					
0.52	14.96		28.4		6	25.8		7	7	34.8		6		17.4		7	
0.55	15.77					27.2		7	7					18.3		7	
0.60	17.12					29.5	17.7	7	7					19.9		7	
0.65	18.47					31.9	19.1	7	7					21.5		7	
0.70	19.82					34.2	20.5	6	7					23.0		7	
0.75	21.08					36.4	21.8	6	7					24.5		7	
0.80	22.30					38.5	23.1	6	7					25.9		7	
0.85	23.53					40.6	24.3	6	7					27.3		7	
0.90	24.75					42.7	25.6	6	7					28.8		6	
0.95	25.98						26.9		7					30.2		6	
1.00	27.20						28.2		6					31.6		6	
1.05	28.43						29.4		6					33.0		6	
1.09	29.35						30.4		6					34.1		6	

### \*Load according to DIN EN 12812:

Dead load  $Q_1 = 0.20 \text{ kN/m}^2$ 

Concrete load  $Q_{2,b} = 24.5 \text{ kN/m}^3 \text{ x d [m]}$ 

Equivalent load: concret-  $Q_4 = 0.10 \times Q_{2-b}$ 

ing  $0.75 \text{ kN/m}^2 \le Q_4 \le 1.75 \text{ KN/m}^2$ 

Equivalent load: working  $Q_{2,p} = 0.75 \text{ kN/m}^2$ 

conditions

Total load  $Q = Q_1 + Q_{2,b} + Q_{2,p} + Q_4$ 

When calculating the prop load. the actual extension length may be used. The exact extension length of the prop when using the SKYDECK drophead is: clear room height minus 0.41 m. Prop loads over 33.3 kN: bolting on of Drophead for use with PEP Slab Props using 2 Bolts DIN EN ISO 4016 M12 x 40-4.6 galv.. Mu.

<sup>\*\*</sup>Deflection according to DIN 18202. assuming perfect levelling.

## **A16 SKYDECK**

## Prop loads with Prophead SSK



				M	ain Bean	n SLT 2	25					М	ain Bear	n SLT 1	50		
둗		Pa	anel span	c 1.50	m	Pa	anel span	c 0.75	m	Pa	anel span	c 1.50	m	Pa	anel span	c 0.75	m
less d [r	N/m²]	Prop [k		Defle line		Prop [k		Defle line			load N]	Defle	ection e**		load N]	Defle line	
Slab thickness d [m]	Load q* [kN/m²]		with Centre Support SSK		with Centre Support SSK		with Centre Support SSK		with Centre Support SSK		with Centre Support SSK		with Centre Support SSK		with Centre Support SSK		with Centre Support SSK
0.14	5.13	17.3		7		8.7		7		11.5		7					
0.16	5.62	19.0		7		9.5		7		12.6		7					
0.18	6.11	20.6		7		10.3		7		13.7		7					
0.20	6.60	22.3		7		11.1		7		14.9		7					
0.22	7.09	23.9		7		12.0		7		16.0		7					
0.24	7.58	25.6		7		12.8		7		17.1		7					
0.25	7.83	26.4		7		13.2		7		17.6		7					
0.26	8.07	27.2		7		13.6		7		18.2		7					
0.28	8.56	28.9	16.2	7	7	14.4		7		19.3		7					
0.30	9.05	30.5	17.1	7	7	15.3		7		20.4		7					
0.35	10.38	35.0	19.6	7	7	17.5		7		23.4		7					
0.40	11.73	39.6	22.2	6	7	19.8		7		26.4		7					
0.43	12.54	42.3	23.7	6	6	21.2		7		28.2		6					
0.45	13.08		24.7		6	22.1		7		29.4		6					
0.50	14.43		27.3		6	24.3		7		32.5		6					
0.55	15.77		29.8		6	26.6		7		35.5		6		17.7		7	
0.60	17.12					28.9		7						19.3		7	
0.65	18.47					31.2	19.0	7	7					20.8		7	
0.70	19.82					33.4	20.4	7	7					22.3		7	
0.75	21.08					35.6	21.7	6	7					23.7		7	
0.80	22.30					37.6	23.0	6	7					25.1		7	
0.85	23.53					39.7	24.2	6	7					26.5		7	
0.90	24.75					41.8	25.5	6	7					27.8		6	
0.95	25.98						26.7		7					29.2		6	
1.00	27.20						28.0		6					30.6		6	
1.05	28.43						29.3		6					32.0		6	
1.09	29.35						30.2		6					33.0		6	

### \*Load according to DIN EN 12812:

Dead load  $Q_1 = 0.20 \text{ kN/m}^2$ 

Concrete load  $Q_{2.b} = 24.5 \text{ kN/m}^3 \text{ x d [m]}$ 

Equivalent load: concreting  $Q_4 = 0.10 \times Q_{2 \cdot b}$ 

 $0.75 \text{ kN/m}^2 \le Q_4 \le 1.75 \text{ KN/m}^2$ 

Equivalent load:  $Q_{2,p} = 0.75 \text{ kN/m}^2$  working conditions

Total load  $Q = Q_1 + Q_{2,p} + Q_{2,p} + Q_4$ 

When calculating the prop load, the actual extension length may be used. The exact extension length of the prop when using the SKYDECK Prophead is: clear room height minus 0.33 m.

<sup>\*\*</sup>Deflection according to DIN 18202, assuming perfect levelling.


### A16 SKYDECK

### Prop loads in panel system Striking guide values



### Panel system

Slab thickness d [m]	Load q* [kN/m²]	Prop load [kN]	* Deflection to DIN 18202, line
0.14	5.13	5.78	7
0.16	5.62	6.33	7
0.18	6.11	6.88	7
0.20	6.61	7.43	7
0.22	7.10	7.98	7
0.24	7.59	8.53	7
0.25	7.83	8.81	7
0.26	8.08	9.09	7
0.28	8.57	9.64	7
0.30	9.06	10.19	7
0.35	10.39	11.69	7
0.40	11.74	13.21	7
0.42	12.28	13.82	6
0.45	13.09	14.73	6
0.50	14.44	16.24	6
0.55	15.79	17.76	6



\* Deflection according to DIN 18202. Assuming perfect levelling.

#### Calculation basis:

\*Load according to EN 12812

Dead load Q<sub>1</sub> 0.20 kN/m<sup>2</sup>

Concrete load Q<sub>2,b</sub> 24.5 kN/m<sup>3</sup> x d [m]

Equivalent load: concreting Q<sub>4</sub>  $0.10 \times Q_{2-b}$ 

 $0.75 \text{ kN/m}^2 \le Q_4 \le 1.75 \text{ KN/m}^2$ Equivalent load: Q<sub>2.p</sub>

0.75 kN/m<sup>2</sup> working conditions

> Total load **Q**  $Q_1 + Q_{2,b} + Q_{2,p} + Q_4$

### Striking guide values\* [Days] for the Drophead System.

Slab thickness d [m]	Required concrete strength f <sub>ck,cube</sub>	*Guide values for striking time [days] for panels and main beams with an average curing temperature [°C] of					
	[N/mm²]	5°	10°	20°			
0.14	15	10	6	5			
0.16	13	8	5	4			
0.18	11	6	4	3			
0.20	9	5	3	2			
0.22	8	4	3	2			
0.25	7	4	2	2			
0.30	6	3	2	2			
0.35	5	3	2	1			
0.40-1.09	5	2	1	1			

The required concrete strength at the time of striking is decisive. This is to be calculated by suitable methods.

Guidelines according to DIN 1045 must also be taken into account, e.g. curing. A minimum of 1.88 cm<sup>2</sup>/m (Q 188) is required for the bottom reinforcement layer. For systems without any centre support of the main beams, a live load of 1 kN/m2 on the slab which has struck early, is to be considered.

\* Guide values according to Leonhard for cement Z 35, CEM I 32.5 R.


## **A17 SKYDECK**


### Filler plates, forming around columns



### Perm. width B [m] of the filler plate

	Case 1	Case 2
Slab thickness d [m]	Fin Ply 21 mm Spruce 400 parallel/cross	Fin Ply 21 mm Spruce 400 parallel/cross
0.14	0.65	0.71
0.16	0.62	0.69
0.18	0.60	0.68
0.20	0.58	0.65
0.22	0.57	0.64
0.24	0.55	0.63
0.25	0.55	0.61
0.26	0.54	0.61
0.28	0.53	0.60
0.30	0.52	0.59
0.35	0.49	0.58
0.40	0.47	0.56
0.43	0.46	0.54
0.45	0.46	0.53
0.50	0.44	0.52
0.52	0.44	0.51
0.55	0.43	0.51
0.60	0.42	0.50
0.65	0.41	0.49
0.70	0.40	0.48
0.75	0.39	0.47
0.80	0.39	0.46
0.85	0.38	0.46
0.90	0.37	0.45
0.95	0.37	0.45
1.00	0.36	0.44
1.05	0.36	0.44
1.09	0.35	0.43





## Perm. width of influence e<sub>B</sub> [m] for shuttering columns


	Pane	l 150	Pan	el 75	
Slab thickness	L/500 =	= 3 mm	L/500 = 1,5 mm		
d [m]	SRT-2	SPH	SRT-2	SPH	
0.14	1.14	0.49			
0.16	1.01	0.43			
0.18	0.90	0.38			
0.20	0.81	0.35			
0.22	0.74	0.32			
0.24	0.68	0.29			
0.25	0.65	0.28			
0.26	0.63	0.27			
0.28	0.59	0.25			
0.30	0.55	0.23			
0.35	0.47	0.20			
0.40	0.41	0.18			
0.43	0.39	0.16	1.70	0.72	
0.45	0.37	0.16	1.63	0.69	
0.50	0.33	0.14	1.48	0.63	
0.52	0.32	0.14	1.43	0.61	
0.55			1.35	0.57	
0.60			1.25	0.53	
0.65			1.16	0.49	
0.70			1.08	0.46	
0.75			1.01	0.43	
0.80			0.96	0.41	
0.85			0.91	0.38	
0.90			0.86	0.37	
0.95			0.82	0.35	
1.00			0.78	0.33	
1.05			0.75	0.32	
1.09			0.73	0.31	

Note:


Deflection single span beam B/300.

### Perm. span L [m] of the Edge Main Beams

Beam used	Slab thickness [m]										
beam used	0.20	0.30	0.40	0.50	0.60	0.70	0.80	0.90	1.00	1.05	1.09
GT 24	4.61	3.93	3.45	3.12	2.86	2.66	2.51	2.26	2.06	1.97	1.91
VT 20	3.89	3.32	2.92	2.63	2.42	2.22	1.97	1.78	1.62	1.55	1.50
KH 10/16	3.79	3.23	2.84	2.56	2.35	2.10	1.86	1.68	1.53	1.46	1.42



### Perm. width B [m] of the filler plate max. 0.40 m



# A18 Slab props



### Permissible prop load [kN] according to the type test

	PEP 20	N 260*	PEP 2	0-300	PEP 2	0-350	PEP 2	0-400	PEP 2	0-500
sion [m]	L = 1.51		L = 1.71	– 3.00 m	L = 1.96	– 3.50 m	L = 2.21	– 4.00 m	L = 2.71	– 5.00 m
Extension length [m]	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom
1.60	35.0	35.0								
1.70	35.0	35.0								
1.80	35.0	35.0	36.4	36.4						
1.90	35.0	35.0	36.4	36.4						
2.00	33.5	35.0	36.1	36.4	36.4	36.4				
2.10	31.9	35.0	33.2	36.4	36.4	36.4				
2.20	30.9	35.0	31.4	36.4	36.4	36.4				
2.30	29.8	35.0	29.9	36.4	36.4	36.4	36.4	36.4		
2.40	28.6	35.0	28.7	36.4	36.4	36.4	36.4	36.4		
2.50	27.1	32.9	27.7	36.4	36.4	36.4	36.4	36.4		
2.60	24.8	29.4	26.9	36.3	34.8	36.4	36.4	36.4		
2.70			25.7	32.7	33.4	36.4	36.4	36.4		
2.80			24.0	29.3	32.1	36.4	36.4	36.4	36.4	36.4
2.90			22.3	26.5	31.1	36.4	36.4	36.4	36.4	36.4
3.00			20.5	23.9	30.1	36.4	36.4	36.4	36.4	36.4
3.10					28.3	35.7	34.6	36.4	36.4	36.4
3.20					26.5	32.5	33.5	36.4	36.4	36.4
3.30					24.8	29.7	32.1	36.4	36.4	36.4
3.40					23.1	27.2	30.5	36.4	36.4	36.4
3.50					21.3	24.8	28.7	34.9	36.4	36.4
3.60							26.9	32.1	36.4	36.4
3.70							25.3	29.8	36.4	36.4
3.80							23.7	27.6	36.4	36.4
3.90							22.3	25.5	36.4	36.4
4.00							20.7	23.5	35.3	36.4
4.10									33.3	36.4
4.20									31.5	36.4
4.30									29.8	35.0
4.40									28.2	32.9
4.50									26.8	30.8
4.60									25.3	28.9
4.70									24.1	27.2
4.80									22.8	25.7
4.90									21.5	24.1
5.00									20.3	22.1

All PEP 20 Props correspond to Class D of DIN EN 1065, i. e. the permissible load for all extension lengths is a minimum of 20 kN.

When using PERI Slab Tables, the permissible load for all PEP 20 Props is a minimum of 30 kN over the entire extension lengths due to the clamping in the Table Swivel Head or UNIPORTAL Head.

\*For the N Props, a use of the inner tube at the bottom is only possible in connection with PERI Slab Tables or SKYDECK (bolted head).

### A18 Slab props PEP 20 with Base MP 50



### Permissible prop load [kN] according to the type test

all height extension cm)	PEP 20	N 260*	PEP 2	0-300	PEP 2	0-350	PEP 2	0-400	PEP 2	0-500
<b>hei</b> tens	L = 1.51		L = 1.71	L = 1.71 – 3.00 m		– 3.50 m	L = 2.21	– 4.00 m	L = 2.71	– 5.00 m
Overall height [m] (prop extension + 50 cm)	Outer tube bottom	Inner tube bottom								
2.10	35.3	35.3								
2.20	35.3	35.3								
2.30	35.3	35.3	35.3	35.3						
2.40	33.2	35.3	35.3	35.3						
2.50	31.0	35.3	33.8	35.3	35.3	35.3				
2.60	29.5	35.3	30.9	35.3	35.3	35.3				
2.70	27.8	35.3	28.7	35.3	35.3	35.3				
2.80	26.5	33.7	27.0	35.3	35.3	35.3	35.3	35.3		
2.90	25.6	29.8	25.6	34.7	35.3	35.3	35.3	35.3		
3.00	23.7	26.7	24.4	31.2	34.0	35.3	35.3	35.3		
3.10	21.6	23.9	23.5	28.0	31.9	35.3	35.3	35.3		
3.20			22.4	25.5	30.2	35.3	35.3	35.3		
3.30			20.7	23.2	28.8	35.3	35.3	35.3	35.3	35.3
3.40			19.3	21.2	27.6	33.2	34.7	35.3	35.3	35.3
3.50			17.5	19.2	26.2	29.8	32.9	35.3	35.3	35.3
3.60					24.6	27.8	31.3	35.3	35.3	35.3
3.70					22.9	25.3	29.9	34.3	35.3	35.3
3.80					21.3	23.5	28.2	31.8	35.3	35.3
3.90					19.8	21.9	26.5	29.1	35.3	35.3
4.00					18.3	20.1	24.8	26.9	35.3	35.3
4.10							23.2	25.3	35.3	35.3
4.20							21.8	23.5	35.3	35.3
4.30							20.4	22.1	34.6	35.3
4.40							19.1	20.6	32.7	35.3
4.50							17.8	19.2	30.7	33.2
4.60									28.4	31.2
4.70									27.2	29.1
4.80									25.7	27.6
4.90									24.3	26.0
5.00									23.1	24.6
5.10									21.9	23.3
5.20									20.8	22.1
5.30									19.7	20.9
5.40									18.5	19.4
5.50									17.6	17.7

<sup>\*</sup>For the N Props, use of the inner tube at the bottom is only possible in connection with PERI Slab Tables or SKYDECK (bolted head).

## A18 Slab props



### Permissible prop load [kN] according to the type test

	PEP 3	0-150	PEP 3	0-250	PEP 3	0-300	PEP 3	0-350	PEP 3	0-400
sion [m]	L = 0.96	– 1.50 m	L = 1.46	– 2.50 m	L = 1.71	– 3.00 m	L = 1.96	– 3.50 m	L = 2.21	– 4.00 m
Extension length [m]	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom
1.00	36.4	36.4								
1.10	36.4	36.4								
1.20	36.4	36.4								
1.30	35.9	36.4								
1.40	35.3	36.4								
1.50	34.5	36.4	42.9	42.9						
1.60			42.9	42.9						
1.70			42.9	42.9						
1.80			42.1	42.9	42.9	42.9				
1.90			39.7	42.9	42.9	42.9				
2.00			37.9	42.9	42.9	42.9	45.5	45.5		
2.10			36.4	42.9	42.9	42.9	45.5	45.5		
2.20			35.5	42.9	42.9	42.9	45.5	45.5		
2.30			34.3	41.5	42.9	42.9	45.5	45.5	41.5	41.5
2.40			33.1	38.7	42.7	42.9	45.5	45.5	41.5	41.5
2.50			31.0	35.9	41.1	42.9	45.5	45.5	41.5	41.5
2.60					40.0	42.9	45.5	45.5	41.5	41.5
2.70					38.5	42.9	45.5	45.5	41.5	41.5
2.80					36.9	41.6	45.5	45.5	41.5	41.5
2.90					34.2	38.3	45.0	45.5	41.5	41.5
3.00					31.3	34.8	43.6	45.5	41.5	41.5
3.10							41.4	44.2	41.5	41.5
3.20							38.7	42.1	41.5	41.5
3.30							36.1	38.7	41.5	41.5
3.40							33.3	35.7	41.5	41.5
3.50							30.7	32.5	41.5	41.5
3.60									41.5	41.5
3.70									41.3	41.5
3.80									38.5	41.3
3.90									35.9	38.1
4.00									33.2	34.9

All PEP 30 Props correspond to Class E of DIN EN 1065, i. e. the permissible load for all extension lengths is a minimum of 30 kN.

When using PERI Slab Tables, the permissible load for all PEP 30 Props is a minimum of 40 kN (PEP 30-150 = 35 kN) over the entire extension lengths due to the clamping in the Table Swivel Head or UNIPORTAL Head.

## A18 Slab props PEP 30 with Base MP 50



### Permissible prop load [kN] according to the type test

<b>ht</b>	PEP 3	PEP 30-250		0-300	PEP 3	0-350	PEP 3	0-400
l <b>heig</b>	L = 1.46	– 2.50 m	L = 1.71	– 3.00 m	L = 1.96	– 3.50 m	L = 2.21	– 4.00 m
Overall height [m] (prop extension + 50 cm)	Outer tube bottom	Inner tube bottom						
2.00	41.6	41.6						
2.10	41.6	41.6						
2.20	41.6	41.6						
2.30	38.9	41.6	41.6	41.6				
2.40	36.1	41.6	41.6	41.6				
2.50	33.9	41.6	41.6	41.6	44.1	44.1		
2.60	32.2	41.0	41.6	41.6	44.1	44.1		
2.70	30.8	38.7	41.6	41.6	44.1	44.1		
2.80	29.7	35.3	40.3	41.6	44.1	44.1	40.3	40.3
2.90	27.5	31.3	38.3	41.6	44.1	44.1	40.3	40.3
3.00	25.9	27.6	36.5	41.3	44.1	44.1	40.3	40.3
3.10			35.1	40.0	44.1	44.1	40.3	40.3
3.20			32.9	36.8	43.8	44.1	40.3	40.3
3.30			31.1	33.2	41.7	44.1	40.3	40.3
3.40			28.5	30.3	38.8	41.8	40.3	40.3
3.50			26.1	27.1	37.1	39.7	40.3	40.3
3.60					34.8	36.5	40.3	40.3
3.70					32.4	33.5	40.3	40.3
3.80					30.0	30.9	40.3	40.3
3.90					27.8	28.7	40.3	40.3
4.00					25.6	26.3	39.4	40.3
4.10						_	36.7	37.9
4.20	_	_				_	34.3	35.2
4.30	_	_				_	32.0	32.9
4.40							29.9	30.5
4.50							27.6	28.2

## A18 Slab props PEP Ergo B



### Permissible prop load [kN] according to type test

	PEP Erg	o B-300	PEP Erg	o B-350		
ë Œ	L = 1.97	– 3.00 m	L = 2.25	L = 2.25 – 3.50 m		
Extension length [m]	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom		
2.00	30.0	30.0				
2.10	29.8	30.0				
2.20	27.0	30.0				
2.30	24.6	30.0	30.0	28.6		
2.40	23.0	30.0	28.6	28.6		
2.50	21.4	30.0	25.5	28.6		
2.60	20.3	29.5	23.1	28.3		
2.70	19.3	27.4	21.2	28.0		
2.80	18.2	24.8	19.8	27.4		
2.90	16.9	22.2	18.6	26.0		
3.00	15.6	20.2	17.5	24.4		
3.10			16.3	22.7		
3.20			15.2	20.8		
3.30			14.2	19.0		
3.40			13.2	17.4		
3.50			12.4	15.7		

### Note:

- PERI PEP Ergo B-300 and PEP Ergo B-350 Props meet the load-bearing capacity requirements of Prop Class B as stipulated in DIN EN 1065.
- General Building Inspectorate Approval Z-8.311-934 issued by the German Institute for Building Technology (DIBt).

### A18 Slab props PEP 30 with Base MP 50



### Permissible prop load [kN] according to type test

	PEP Erg	jo D-150	PEP Erg	o D-250	PEP Erg	o D-350	PEP Erg	o D-400	PEP Erg	o D-500
<u>E</u> <u>o</u>	L = 0.98	– 1.50 m	L = 1.47	– 2.50 m	L = 2.26	– 3.50 m	L = 2.51	– 4.00 m	L = 3.26	– 5.00 m
Extension length [m]	Outer tube bottom	Inner tube bottom								
1.00	30.0	30.0								
1.10	30.0	30.0								
1.20	30.0	30.0								
1.30	30.0	30.0								
1.40	28.4	30.0	25.0	25.0						
1.50	26.4	30.0	35.0	35.0						
1.60			35.0	35.0						
1.70 1.80	_		32.8 30.7	35.0 35.0						
1.80			29.1	35.0						
2.00			28.1	35.0						
2.10			27.2	35.0						
2.20			26.4	34.0						
2.30			25.7	32.3	40.0	40.0				
2.40			24.2	29.4	40.0	40.0				
2.50			22.4	26.2	40.0	40.0				
2.60					37.8	40.0	40.0	40.0		
2.70					35.1	40.0	40.0	40.0		
2.80					33.0	40.0	40.0	40.0		
2.90					31.1	40.0	40.0	40.0		
3.00					29.6	40.0	40.0	40.0		
3.10					28.1	38.6	37.7	40.0		
3.20					26.9	34.7	35.6	40.0		
3.30					25.0	31.5	33.7	40.0	40.0	40.0
3.40					23.1	28.6	32.3	40.0	40.0	40.0
3.50					21.2	25.8	30.7	39.3	40.0	40.0
3.60							28.6	35.9	40.0	40.0
3.70	-						26.7	32.9	40.0	40.0
3.80							24.9	30.2	40.0	40.0
3.90							23.1	27.8	40.0	40.0
4.00 4.10							21.4	25.3	40.0 39.0	40.0 40.0
4.10									39.0	40.0
4.20									33.8	39.0
4.40									31.6	36.7
4.50									29.6	34.3
4.60									27.8	32.1
4.70			1						26.1	30.1
4.80									24.5	28.2
4.90									23.0	26.4
5.00									21.4	24.7

#### Note:

- PERI PEP Ergo D-150, PEP Ergo D-250, PEP Ergo D-350, PEP Ergo D-400 and PEP Ergo D-500 Props fulfil Prop Class D load-bearing capacity requirements of DIN EN 1065.
- In addition, the PEP Ergo D-250 Prop fulfils Prop Class B requirements as stipulated in DIN EN 1065.
- General Building Inspectorate Approval Z-8.311-934 for PERI PEP Ergo D-150 and PEP Ergo D-250.
- General Building Inspectorate Approval Z-8.311-941 for PERI PEP Ergo D-350, PEP Ergo D-400 and PEP Ergo D-500.

## A18 Slab props PEP Ergo B



### Permissible prop load [kN] according to type test

	PEP Erg	o E-300	PEP Erg	o E-400
<u>n</u> <u>[</u>	L = 1.96	– 3.00 m	L = 2.51	– 4.00 m
Extension length [m]	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom
2.0	50.4	50.4		
2.1	50.4	50.4		
2.2	50.4	50.4		
2.3	50.4	50.4		
2.4	50.4	50.4		
2.5	48.9	50.4		
2.6	46.2	50.3	50.4	50.4
2.7	44.4	48.8	50.4	50.4
2.8	42.5	46.7	50.4	50.4
2.9	40.5	44.0	50.4	50.4
3.0	38.0	39.6	50.4	50.4
3.1			50.4	50.4
3.2			50.4	50.4
3.3			50.4	50.4
3.4			50.4	50.4
3.5			48.1	50.4
3.6			45.4	50.4
3.7			42.1	47.4
3.8			39.1	43.7
3.9			36.2	39.8
4.0			33.1	35.3

#### Note:

- PERI PEP Ergo E-300 and PEP Ergo E-400 Props fulfil Prop Class E load-bearing capacity requirements of DIN EN 1065.
- General Building Inspectorate Approval Z-8.311-941 of the German Institute for Building Technlogy (DIBt).

# **A18 Slab props** MULTIPROP 250, 350, 480, 625



### Permissible prop load [kN] according to the type test

		<b>250</b> – 2.50 m		<b>350</b> – 3.50 m	MP L = 2.60		MP L = 4.30	
Extension length [m]	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube bottom	Outer tube bottom	Inner tube
1.45	75.5	78.5						
1.50	75.5	78.5						
1.60	75.5	78.5						
1.70	75.5	78.5						
1.80	73.8	78.5						
1.90	70.6	78.5						
1.95	68.0	78.5	91.0	90.1				
2.00	67.3	78.5	91.0	90.1				
2.10	65.7	76.8	86.0	90.1				
2.20	64.1	75.1	80.6	90.1				
2.30	62.5	72.6	75.1	89.8				
2.40	60.8	69.1	70.7	87.9				
2.50	59.2	65.6	66.4	86.1				
2.60			63.7	83.1	88.5	73.6		
2.70			61.1	80.1	83.7	73.3		
2.80			59.2	77.1	78.8	72.9		
2.90			57.4	74.1	74.0	72.6		
3.00			56.0	70.3	69.1	72.2		
3.10			54.5	66.6	64.9	71.4		
3.20			52.9	61.8	60.7	70.7		
3.30			51.3	57.1	56.5	70.0		
3.40			47.7	51.7	54.1	68.2		
3.50			44.2	46.4	51.8	66.5		
3.60					49.4	64.7		
3.70					47.5	60.4		
3.80					45.7	56.1		
3.90					43.8	51.8		
4.00					41.8	48.4		
4.10					39.7	45.0		
4.20					37.7	41.6		
4.30					35.8	39.3	57.9	45.7
4.40					33.9	37.0	56.3	45.7
4.50					32.0	34.8	54.7	45.7
4.60					30.2	32.5	52.5	45.1
4.70					28.3	30.2	50.3	44.4
4.80					26.4	27.9	47.9	43.5
4.90							45.2	42.4
5.00							42.5	41.3
5.10							39.9	39.9
5.20	MULTIPROP	Props are cl	assified acco	rding to offic	ial approval a	s follows:	37.2	38.5
5.30	MP 250 Clas	-		MP 480 Class			34.9	37.1
5.40	MP 350 Clas			MP 625 Class			32.8	35.6
5.50		.5 11 00		1411 020 01033	2 00		30.8	34.1
5.60	Note:	-   - 00	.N	and the second	- LID \\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Coordinate	29.3	32.6
5.70			in, we recomr	nena using the	e HD Wingnut	Spanner,	27.8	31.2
5.80	Item no. 022027. 26.4 29.6							
5.90	When using PERI Slab Tables, the permissible load of the MULTIPROP MP 350							
6.00	Prop is a minimum of 56 kN and a minimum of 36 kN for the MP 480 over the							
6.10	entire extension length which is due to the clamping in the Table Swivel Head or 22.7 24.8							
6.20	UNIPORTAL Head. 21.6 23.4							
6.25	1						21.0	22.7







Item no.	Weight kg
061000	15.500
061011	11.700
061020	9.780
061010	8.560
061013	6.350
061030	5.250

Panels SDP
Panel SDP 150 x 75
Panel SDP 150 x 50
Panel SDP 150 x 37.5
Panel SDP 75 x 75
Panel SDP 75 x 50
Panel SDP 75 x 37.5
Panel with 9 mm plywood.

	L	В	
Ī	1500	750	
	1500	500	
	1500	375	
	750	750	
	750	500	
	750	375	







061160 25.700

Main Beam SLT 375

For cantilevers.







061100 15.600

Main Beam SLT 225

For standard fields.









 Item no.
 Weight kg

 061110
 9.690

Main Beam SLT 150

For filler areas.







061026	1.580
061027	0.794
061024	0.524
061038	0.400

Cover Strips SAL Cover Strip SAL 150 Cover Strip SAL 75 Cover Strip SAL 50 Cover Strip SAL 37.5

L

Plastic. Panel with 21 mm plywood. For use with drophead SFK.






061045	5.740
061046	2.720

Edge Beams SRT-2 Edge Beam SRT-2 150 Edge Beam SRT-2 75

For longitudinal and transverse filling, for shuttering around columns. Panel with 21 mm plywood.










Item no. Weight kg 061210 6.180

Drophead SFK

With self-locking coupling. Supports main beam as well as cover strip and formlining. Lowering height 6 cm. For 21 mm plywood formlining.








061200 3.860

**Prophead SSK** 

With self-locking coupling. Supports main beams, panels, edge girders and filler timber.









061180


5.340

**Combihead SCK** 

With self-locking coupling. Supports main beams, panels, edge girders and filler timber.











Item no.	Weight kg
061049	3.350
061036	5.020

Filler Timbers SPH Filler Timber SPH 150 Filler Timber SPH 225

For compensations with 21 mm plywood formlining.







061021	8.660
061022	5.350

Triangular Frames SDR
Triangular Frame SDR 150 x 75
Triangular Frame SDR 75 x 75

For compensations on inclined walls. For compensations with 21 mm plywood formlining.







061051 5.250

### Wall Holder SWH-2

For horizontal anchoring at the wall. Attach to every second girder or panel.








Item no. Weight kg

061023 2.140

### **End Support SSL**

To be used as compensation to the filler area and to be fixed to the drophead SFK.





061290

0.133

### Panel Clip SPK

Fixes panel on main beam.





061280

0.778

### Panel Wedge Clip SPKK

Fixes panel on main beam.







061052

2.590

### **Table Connector STV**

For assembling SKYDECK Slab Tables. Also allows the fixing of intermediate props at the main beam.









061300

2.240

### **Erection Aid SSH**

For forming with SKYDECK. Adjustable in 7.5-cm-increments.







Item no. Weight kg 061310 0.996

Tension Sleeve SAO

For bracing cantilevered main beams.



Permissible tension force 3.0 kN.








123633

12.100

**Tension Unit SD** 






061060 108.000

### Platform SDB 150


Work and safety scaffold. Scaffold width 1.30 m. With continuous 39 mm thick decking and foldable handrail frame.

### **Technical Data**

Permissible load 150 kg/m<sup>2</sup>.








061061 153.000


### Platform SDB 225

Work and safety scaffold. Scaffold width 1.30 m. With continuous 39 mm thick decking and foldable handrail frame.

### **Technical Data**

Permissible load 150 kg/m<sup>2</sup>.








Item no. Weight kg 061062 185.000


Platform SDB 300

Work and safety scaffold. Scaffold width 1.30 m. With continuous 39 mm thick decking and foldable handrail frame.

**Technical Data** 

Permissible load 150 kg/m<sup>2</sup>.






061250 4.760


Guardrail Holder SGH, Alu

For assembling a guardrail with SKYDECK.

**Technical Data** 

Maximum width of influence 1.55 m.





Accessories


061260 6.150 Guardrail Post SGP

061260 6.150

**Guardrail Post SGP** 

As guardrail for different systems.








Item no. Weight kg


065073 1.370

Anchor Chain 3.0 kN, I = 2.5 m

### **Technical Data**

Permissible tension force 3.0 kN.





065074


0.450

Turnbuckle 3.0 kN, M12

### **Technical Data**

Permissible tension force 3.0 kN.





028100 1.830


### **Base Plate for RS**

For assembly of RS Push-Pull Props.

### Complete with

1 pc. 018050 Pin Ø 16 x 65/86, galv. 1 pc. 018060 Cotter Pin 4/1, galv.







124777 0.210


### Anchor Bolt PERI 14/20 x 130

For temporary fixation to reinforced concrete structures.

#### Note

See PERI data sheet! Drilling Ø 14 mm.






123970 0.047


### Screw-On Sleeve PERI M16/164

For temporary mounting of components on reinforced concrete slabs.

### Note

Inserted into the fresh concrete immediately after concreting.





Accessories

123973

0.240

Bolt ISO 4014 M16 x 130-8.8, galv.



Item no. Weight kg

061530 82.400

### Pallet SD 150 x 225, galv.

For stacking and transportation of 48 SKYDECK Panels 150 x 75.

### Complete with


5 pc. 100707 Lashing 25 x 5750 mm


### Note


Follow Instructions for Use!

### **Technical Data**

Permissible load-bearing capacity 750 kg.







061500 76.700

### Pallet SD 150 x 75, galv.


For stacking and transportation of 14 SKYDECK Panels 150 x 75.


### Note

Follow Instructions for Use!

### **Technical Data**

Permissible load-bearing capacity 1.0 t.







105.000 ltem no. Weight kg

Pallet Lifting Trolley 1800 mm


For moving pallets and crate pallets.

Note

Follow Instructions for Use!

### **Technical Data**

Forklift arm length 1800 mm, forklift arm width 550 mm, stroke range 115 mm. Permissible load-bearing capacity 2.0 t.



061520 403.000

Transportation Fork SUG, galv.

For moving SKYDECK Slab Tables.


Note

Follow Instructions for Use!

### **Technical Data**

Permissible load-bearing capacity 1.0 t.







Item no. Weight kg 035500 72.800

Stripping Cart, Alu


Mobile working scaffold. Height-adjustable in 25-cm-increments. Platform height max. 2.00 m.


Note

Follow Instructions for Use!

**Technical Data** 

Permissible load 100 kg/m<sup>2</sup>.







Item no. Weight kg 102031 363.000

Stripping Cart ASW 465, compl.

Mobile working scaffold. Height-adjustable in 30-cm-increments. Platform height max. 4.65 m.

Packed in:

Ring Pallet USP 104 Item no. 100678, with Lashing Strap 25 x 5750 Item no. 100707 (x 1) and Scaffold Tube Steel L = 1000 Item no. 100706 (x 6).

Complete with

1 pc. 102025 Folding Base Unit 160/190 ASW

6 pc. 102035 Vertical Frame 70/90 ASW

6 pc. 102034 Vertical Frame 70/120 ASW

2 pc. 102026 Entry Platform 190 ASW

1 pc. 102030 Toe-Board Set 70/190 ASW

4 pc. 102027 Double Guardrail 190 ASW

3 pc. 102028 Diagonal Brace 210 ASW

2 pc. 102029 Horizontal Brace 190 ASW

12 pc. 102807 Ballast 10 kg ASW 2 pc. 103040 Lateral complete ASW


1 pc. 102587 Center part ASW galv.

Note

Follow Instructions for Use!

**Technical Data** 

Permissible load 100 kg/m<sup>2</sup>.






750


1030

Item no.	VVeight kg
118331	13.500
118323	18.000

Handrail Units SD **Handrail Unit SD 75** Handrail Unit SD 150

For assembling a Guardrail on a casting segment with SKYDECK. Assembling in a rectangular angle on top of the Main Beams.






126630 123.000

### Pallet Handrail Unit SD 75

For stacking and transportation of 10 SKYDECK Handrail Units SD 75.




### Note

Follow Instructions for Use!

### **Technical Data**

Permissible load-bearing capacity 150 kg.





Item no. Weight kg 126580 134.000

Pallet Handrail Unit SD 150


For stacking and transportation of 10 SKYDECK Handrail Units SD 150.


Note

Follow Instructions for Use!

### **Technical Data**

Permissible load-bearing capacity 200 kg.







118622 4.870

**Transition Prophead SDSK** 

For the rectangular change of the direction of the Main Beam SLT in the standard application with Prophead SSK.









127620


6.790

**Transition Head SDFK** 

For the rectangular change of the direction of the Main Beam SLT in the standard application with Drophead SFK.







# The optimal System for every Project and every Requirement



Wall Formwork



Column Formwork



Slab Formwork



**Climbing Systems** 



**Bridge Formwork** 



**Tunnel Formwork** 



Shoring Systems



**Construction Scaffold** 



**Facade Scaffold** 



**Industrial Scaffold** 



Access



**Protection Scaffold** 



Safety Systems



**System-Independent Accessories** 



Services



PERI GmbH
Formwork Scaffolding Engineering
Rudolf-Diesel-Strasse 19
89264 Weissenhorn
Germany
Tel. +49 (0)7309.950-0
Fax +49 (0)7309.951-0
info@peri.com
www.peri.com